



Service Manual

242D SKID STEER LOADER

SN: DZT

Note: Use Bookmarks panel to navigate

Printed by Heavy Equipment Manuals
v2.20

Printed in U.S.A

[Heavy Equipment Manuals](#)

Disassembly and Assembly _____	2
Schematic _____	579
Specifications _____	668
Systems Operation _____	770
Torque Specifications _____	2595
Troubleshooting _____	2651

UENR3278-07 C3.3B Tier 4 Final and EU Stage 3B Engines _____	2
UENR3728-01 259D, 279D and 289D Compact Track Loaders _____	178
UENR3730-07 259D, 279D, 299D and 299D XHP Compact Track Loaders _	251
UENR3731-03 259D, 279D, 299D and 299D XHP Compact Track Loaders _	396

Alternator - Remove and Install _____	3
Bearing Clearance - Check _____	5
Boost Pressure Sensor - Remove and Install _____	8
Bridge Dowels - Remove and Install _____	10
Camshaft and Valve Lifters - Remove and Install _____	13
Camshaft Gear - Remove and Install _____	18
Camshaft Position Sensor - Remove and Install _____	21
Camshaft Position Sensor Bushing - Remove and Install _____	23
Connecting Rod Bearings - Remove and Install _____	26
Coolant Temperature Sensor - Remove and Install _____	32
Crankshaft and Main Bearings - Install _____	34
Crankshaft and Main Bearings - Remove _____	39
Crankshaft Front Seal - Remove and Install _____	43
Crankshaft Position Sensor - Remove and Install _____	46
Crankshaft Pulley - Remove and Install _____	48
Crankshaft Rear Seal and Wear Sleeve - Install - Includes Crankshaft Gear _	50
Crankshaft Rear Seal and Wear Sleeve - Remove - Includes Crankshaft Gear _____	52
Cylinder Head - Remove and Install _____	55
Diesel Particulate Filter - Assemble _____	61
Diesel Particulate Filter - Disassemble _____	64
Diesel Particulate Filter - Remove and Install _____	66
Electric Starting Motor - Remove and Install _____	70
Electronic Unit Injector - Remove and Install _____	72
Engine Oil Cooler - Remove and Install _____	76
Engine Oil Pan - Remove and Install _____	78
Engine Oil Pressure Sensor - Remove and Install _____	80
Engine Oil Pump - Remove and Install _____	82
Engine Oil Relief Valve - Remove and Install _____	86
Exhaust Gas Recirculation Valve - Remove and Install _____	88

Exhaust Manifold - Remove and Install _____	91
Flywheel - Remove and Install _____	93
Flywheel Housing - Remove and Install _____	98
Fuel Injection Lines - Remove and Install _____	101
Fuel Injection Pump - Remove and Install _____	103
Fuel Manifold (Rail) - Remove and Install _____	108
Fumes Disposal Filter - Remove and Install _____	111
Glow Plugs - Remove and Install _____	113
Housing (Front) - Remove and Install _____	116
Idler Gear - Remove and Install _____	120
Inlet Air Temperature Sensor - Remove and Install _____	124
Inlet and Exhaust Valve Guides - Remove and Install _____	126
Inlet and Exhaust Valve Springs - Remove and Install _____	129
Inlet and Exhaust Valves - Remove and Install _____	134
Inlet Manifold - Remove and Install _____	138
Pistons and Connecting Rods - Assemble _____	140
Pistons and Connecting Rods - Disassemble _____	146
Pistons and Connecting Rods - Remove and Install _____	150
Pressure Sensor (Mass Air Flow) - Remove and Install _____	155
Rocker Shaft - Assemble _____	159
Rocker Shaft - Disassemble _____	161
Rocker Shaft and Push Rod - Remove and Install _____	163
Turbocharger - Remove and Install _____	165
Valve Mechanism Cover - Remove and Install _____	168
V-Belts - Remove and Install _____	170
Water Pump - Remove and Install _____	172
Water Temperature Regulator - Remove and Install _____	174

Previous Screen

Product: SKID STEER LOADER
Model: 242D SKID STEER LOADER DZT
Configuration: 242D Skid Steer Loader DZT00001-UP (MACHINE)

Disassembly and Assembly

C3.3B Tier 4 Final and EU Stage 3B Engines for Caterpillar Built Machines

Media Number -UENR3278-07

Publication Date -01/09/2014

Date Updated -11/07/2016

i05210953

Alternator - Remove and Install

SMCS - 1405-010

Removal Procedure

Start By:

- a. Remove V belt.
1. Turn the battery disconnect to the OFF position.




Illustration 1

g02798717

2. Disconnect harness assemblies (2) and (3) from alternator (1).
3. Remove nut (4).




Illustration 2


g02798718

4. Remove nut (7) and pulley (6).
5. Remove bolts (5) and (6).
6. Remove alternator (1).

Installation Procedure

1. Install alternator (1) in the reverse order of removal.
 - a. Ensure pulley (6) is correctly oriented.
 - b. Tighten nut (7) to a torque of 58 to 79 N·m (43 to 58 lb ft).

[Previous Screen](#)

 **Product:** SKID STEER LOADER
Model: 242D SKID STEER LOADER DZT
Configuration: 242D Skid Steer Loader DZT00001-UP (MACHINE)

Disassembly and Assembly

C3.3B Tier 4 Final and EU Stage 3B Engines for Caterpillar Built Machines

Media Number -UENR3278-07

Publication Date -01/09/2014

Date Updated -11/07/2016

i05221757

Bearing Clearance - Check

SMCS - 1203-535; 1219-535

Measurement Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	198-9142	Plastic Gauge (Green) 0.025 to 0.076 mm (0.001 to 0.003 inch)	1
	198-9143	Plastic Gauge (Red) 0.051 to 0.152 mm (0.002 to 0.006 inch)	1
	198-9144	Plastic Gauge (Blue) 0.102 to 0.229 mm (0.004 to 0.009 inch)	1
	198-9145	Plastic Gauge (Yellow) 0.230 to 0.510 mm (0.009 to 0.020 inch)	1

Note: Refer to Specification UENR3421 "Engine Design" for non-specified engine Torque Values.

Note: Plastic gauge may not be necessary when the engine is in the chassis.

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

Note: Caterpillar does not recommend the checking of the actual bearing clearances particularly on small engines. The checking can result in the possibility of obtaining inaccurate information and the possibility of damaging the bearing or the journal surfaces. Each Caterpillar engine bearing is quality checked for specific wall thickness.

Note: The measurements should be within specifications and the correct bearings should be used. If the crankshaft journals and the bores for the block and the rods were measured during disassembly, no further checks are necessary. However, if the technician still wants to measure the bearing clearances, Tooling (A) is an acceptable method. Tooling (A) is less accurate on journals with small diameters if clearances are less than 0.10 mm (0.004 inch).

NOTICE

Lead wire, shim stock or a dial bore gauge can damage the bearing surfaces.

The technician must be careful to use Tooling (A) correctly. The following points must be remembered:

- Ensure that the backs of the bearings and the bores are clean and dry.
- Ensure that the bearing locking tabs are properly seated in the tab grooves.
- The crankshaft must be free of oil at the contact points of Tooling (A).

1. Put a piece of Tooling (A) on the crown of the bearing that is in the cap.

Note: Do not allow Tooling (A) to extend over the edge of the bearing.

2. Use the correct torque-turn specifications in order to install the bearing cap. Do not use an impact wrench. Be careful not to dislodge the bearing when the cap is installed.

Note: Do not turn the crankshaft when Tooling (A) is installed.

3. Carefully remove the cap, but do not remove Tooling (A). Measure the width of Tooling (A) while Tooling (A) is in the bearing cap or on the crankshaft journal. Refer to Illustration 1.
-




Illustration 1
Typical Example

g01152855

4. Remove all of Tooling (A) before you install the bearing cap.

Note: When Tooling (A) is used, the readings can sometimes be unclear. For example, all parts of Tooling (A) are not the same width. Measure the major width in order to ensure that the parts are within the specification range. Refer to Specifications Manual, "Connecting Rod Bearing Journal" and Specifications Manual, "Main Bearing Journal" for the correct clearances.

Previous Screen

Product: SKID STEER LOADER
Model: 242D SKID STEER LOADER DZT
Configuration: 242D Skid Steer Loader DZT00001-UP (MACHINE)

Disassembly and Assembly

C3.3B Tier 4 Final and EU Stage 3B Engines for Caterpillar Built Machines

Media Number -UENR3278-07

Publication Date -01/09/2014

Date Updated -11/07/2016

i05226369

Boost Pressure Sensor - Remove and Install

SMCS - 1917-010

Removal Procedure




Illustration 1

g03339024

1. Disconnect harness assembly (4). Remove hose (3). Remove bolts (2) to remove boost pressure sensor (1).

Installation Procedure

1. Install boost pressure sensor (1) in the reverse order of removal.
 - a. Tighten bolts (2) to a torque of 4 N·m (35 lb in) 5 N·m (44 lb in).