


**CLARK** Material Handling  
Europe

# **CGP / CDP 16-50 H**

## **Hydrostatic Transmission**

---



## **Service Manual**

---


**SM 5190 GEF GB**


## **GROUP 06 (H)**





### **Hydrostatic Transmission**

Specification and Description .....	Section 1
Elektronic-Control .....	Section 2
Service Manual Variable Displacement Pump .....	Section 3
Service Manual Drive Axle CDP/CGP 16-20H (MCR 3) .....	Section 4
Service Manual Drive Axle CDP/CGP 20-35H (MCR 5) .....	Section 5
Service Manual Drive Axle CDP/CGP 40-50H (MCR 10) .....	Section 6
Diagrams .....	Section 7
Actuators-Throttle Governor & Brake Valves .....	Section 8
Service-Information .....	Section 9


## 8.13 Automatic General Setup

This menu will be shown if you select number <13> and  in the Main Menu.




- By pushing  and  you start the automatic general setup procedure.
- The automatic general setup starts sequentially the menus <2>, <3>, <4>, <5> and <11>.
- By pushing  and  you go back to the Main Menu.





## 8.14 EDC min. Current Setup

This menu will be shown if you select number <14> and  in the Main Menu.



**CAUTION:** For this setup we recommended to lift up the vehicle and the engine must run!



- By pushing  and  you go back to the Main Menu.
- By pushing  and  you start the EDC min. current setup procedure.

**8.14.1 EDC min. Current Setup Procedure**

This menu will be shown if you select number **1** and **←** in the EDC min. Current Setup Menu. You have to follow the status lines shown on the screen. The new parameters of the sensor will be shown behind each status line.

----- Minimum EDC Current Setup -----

Output current forward : 10 mA  
Output current reverse : 10 mA

Active direction : [NEUTRAL]

Use the following key to control the setup:

<Q> = Quit the setup and save  
<+> = Increase current      <-> = Decrease current  
<F> = Forward direction      <R> = Reverse direction  
<N> = Neutral

Ok Cancel

- Block one wheel.
- Select forward direction <F>.
- Increase current <+> until the wheel starts to turn forward.
- Select reverse direction <R>.
- Increase current <+> until the wheel starts to turn reverse.
- Select <Q> to save the parameters and go back to the Main Menu.

If the setup detects an error during the learning phase, the system will display an error screen with a detailed error description.

----- Minimum EDC Current Setup -----


<SETUP ERROR> : Minimum value too low.

Push <RETURN> please. 0

Ok Cancel



### 8.15 EDC max. Current Setup

This menu will be shown if you select number <15> and  in the Main Menu.







**CAUTION:** For this setup we recommended to lift up the vehicle and the engine must run!

Set new MAXIMUM EDC Current (Yes=1, No=0) : 0



Engine must run !

Truck must be lift up !!!!

Ok Cancel

- By pushing  and  you go back to the Main Menu.
- By pushing  and  you start the EDC max. current setup procedure.

#### 8.15.1 EDC max. Current Setup Procedure

This menu will be shown if you select number  and  in the EDC max. Current Setup Menu. You have to follow the status lines shown on the screen. The new parameters of the sensor will be shown behind each status line.

----- Maximum EDC Current Setup -----

Output current forward : 35 mA

Output current reverse : 35 mA

Active direction : [NEUTRAL]

Use the following key to control the setup:

<Q> = Quit the setup and save

<+> = Increase current      <-> = Decrease current



<F> = Forward direction      <R> = Reverse direction

<N> = Neutral


Ok Cancel

- Block one wheel.
- Select forward direction <F>.
- Increase current <+> until the wheel reaches the maximum RPM speed.
- Select reverse direction <R>.
- Increase current <+> until the wheel reaches the maximum RPM speed.
- Select <Q> to save the parameters and go back to the Main Menu.

### 8.16 Disable Brake & Antistall

If this menu point is called, the system will disable the brake and antistall function. This function can be used to rub the brakes at the first time. Or to adjust the LP-Engine (driving again the brake to get a load on the engine). This function will be automatically disabled if the truck is switched off, or if the „Run Screen“ (truck is running) is deactivated by a system reset ( ).

### 8.17 Ramp Setup

In this menu you can change the parameters of the acceleration and deceleration characteristic of the machine. You have to select number <17> and  in the Main Menu.

----- Ramp Parameter (all units are ms) -----

RPM for second acceleration :

Linear acceleration:

First (100..2500) :	<input type="text" value="1000"/>	Second (100..2500) :	<input type="text" value="1500"/>
---------------------	-----------------------------------	----------------------	-----------------------------------

Linear deceleration: (100..2500)

Forward --> Freewheeling :	<input type="text" value="1500"/>	Neutral :	<input type="text" value="1500"/>	Reversal :	<input type="text" value="750"/>
Reverse --> Freewheeling :	<input type="text" value="1500"/>	Neutral :	<input type="text" value="1500"/>	Reversal :	<input type="text" value="750"/>

Throttle request :

Ramp TAU up min. :	<input type="text" value="100"/>	Ramp TAU down min. :	<input type="text" value="100"/>
Ramp TAU up max. :	<input type="text" value="1500"/>	Ramp TAU down max. :	<input type="text" value="250"/>

Vehicle speed for faster deceleration (1..1000) :

Ramp for faster deceleration (min. 200) :

<ESC> - Abort   <TAB> - next Parameter   <RETURN> - OK








Figure 10: Characteristic of the acceleration




Figure 11: Direction switch switches from forward to neutral or from reverse to neutral.




Figure 12: Direction switch switches from forward to reverse or from reverse to neutral.






Figure 13: Characteristic of the deceleration



The deceleration ramp is based on the following characteristic. The ramp starts with a non linear part, followed by a linear part and ended also by a non linear part. This three parts are independent of each other. The non linear parts are the same in all different driving conditions. The linear part is adjustable dependent on direction and function.

Figure 14: Characteristic of the ramp system


dt=10; kp=1000; TR=1500; T2=500; T1=500








## 8.20 Service Adjustment

In this menu you will find the most important parameters to change the driving characteristics. You have to select number <20> and  in the Main Menu.



```

----- Service Adjustments -----

High idle position (10 .. 100) : 50
Engine RPM --> Low idle       : 400
Engine RPM --> High idle      : 2450

Engine RPM start controller    : 874
RPM max. controller           : 1600

RPM      (%) 1. automotive curve (1..100) : 30
Current  (%) 1. automotive curve (< RPM %) : 30
Throttle (%) setpoint curve    (1..100)   : 14
Ne       (%) setpoint curve    (< Throttle %) : 80

Actuator Ramp Tau-Up: RPM-Breakpoint : 1300
                    First (10..1000ms) : 10
                    Second (10..1000ms) : 500

<ESC> - Abort   <TAB> - next Parameter  <RETURN> - OK
  
```

High idle position (10..100)

: This value limits the function of the position control loop (i.e. a value of 50 means, that if the engine speed setpoint is High Idle, the position of the lever is set to 50%. The rest of the speed difference is done by the governor control loop).

Engine RPM low idle

: Min. engine speed.

Engine RPM high idle

: Max. engine speed.

RPM start controller

: Start diesel RPM of the automotive curve.

RPM max. controller

: Max. diesel RPM of the automotive curve (RPM 17°).

RPM (%)

: Kink point of the setpoint (%) of the max. setpoint.

Current (%)

: Current value in the kink point of the output curve (%) (<RPM %) from the max. output current (1...10).

Throttle (%)

: Kink point of the throttle position (%) of the max. throttle position (1...10).

Ne (%)

: Ne setpoint value in the kink point of the output curve (%) from the max. Ne setpoint (1...10).

Ramp Tau up RPM-Breakpoint

: RPM setpoint between ramp up 1<sup>st</sup> and ramp up 2<sup>nd</sup>.




Ramp TAU up 1<sup>st</sup> (10..1000ms)

: Delay time for rising edge below RPM-breakpoint.

Ramp TAU up 2<sup>nd</sup> (10..1000ms)




: Delay time for rising edge above RPM-breakpoint.

### 9. Run Mode Screens

You leave the **Setup Mode** and enter the **Run Mode** by entering a <0> followed by a  in the Main Menu. Once you have entered the **Run Mode** the first of the available run screens is displayed and the SUSMIC Digital System starts working. To return to the **Setup Mode** from the Run Mode enter  .

There are several **Run Screens** available which can be activated by entering an appropriated key (for a list of these keys and their corresponding **Run Screens** see Chapter later). Find a list of all **Run Screens** and their description in the following.

#### 9.1 Run Screen

This **Main Run Screen** will be shown if you select number <0> and  in the Main Menu or enter the key combination   in **Run Mode**. The data screen is displayed and the control system starts working.

```

***** Run Screen *****

Engine RPM : 2443
EDC current (mA * 10) : 0 0 Droop : 0
Brake A/D value / Brake Indc : 154 450 Park brake : [ NO ]
Vehicle speed (%) : 0

Throttle A/D value / No setpoint : 763 699

Direction : [ NEUTRAL ] System mode: [ STOP ]
PIDT position output: -183
Actuator feedback : 64 AbsSetpError: -3023 PosRPMSet : 0
E-Actuator setpoint : 699 PWM CW : 0 PWM CCW : 183
Lift setpoint : 699 Lift A/D : 50
Tilt RPM active : [ NO ] Error : [ YES ]

-- <Shift + R> Main Menu, <Shift + E> Error Screen --
-- <Shift + S> Service Screen, <?> Help Screen
-- <Shift + P> Setup Errors, <Shift + O> Operation Errors --

Ok Cancel
    
```

- On the upper 2/3 of the screen the system data in alphanumeric format are shown.