

Service Manual

SM 607G



GT 30E-50E-60E

**Gas
Towing
Tractors**

CLARK

Technical
Publications
Lexington, KY
40507-1640

Copyrighted Material
Intended for CLARK dealers only
Do not sell or distribute


Alphabetical Index

Air Induction System	Group 03
Alternator	Group 14
Brake System	Group 23
Cooling System	Group 01
Counterweight	Group 38
Drive Axle	Group 20
Electrical System	Group 14
Engines	Group 00
Fuel System	Group 02
Ignition System	Group 12
Jacking & Blocking	Group SA
Oil Change	Group 00
Planned Maintenance	Group PS
Parking Brake	Group 23
Radiator	Group 01
Safety	Group SA
Sheet Metal, & Chassis	Group 38
Shop Supplies	Group 40
Specifications	Group 40
Starter	Group 14
Steer Axle	Group 26
Steering	Group 25
Transmission	Group 06
Tune-Up	Group 00
U-Joint	Group 21
Water Pump	Groups 01, 00
Wheels/Tires	Group 22


Section 1.

Engine & Transmission Removal-Gas & LPG


With the exception of the seat deck, the tow tractor sheet metal is not particularly heavy. It is however, cumbersome. One person should not try to remove it alone. This is a two person job. Also, the drive line removal and reinstallation requires two people. The engine must be lifted with the fan end at an up angle and then moved forward to get the parking brake on the transmission past the seat support structure of the frame. One person trying to do this alone can result in damage to the truck or drive line components.




1. Lift hood onto prop. Pull the fastpins and lift hood from truck.




2. Unbolt and remove the tunnel and tunnel support.




3. Unbolt and remove firewall and cover plate.




4. Remove seat and seat deck. These can be removed as a unit but the seat deck is easier to remove if the seat is taken off first.



5. On the LPG truck it is also necessary to remove the LPG tank and tank guard.




6. Raise and block front of truck and remove the steer wheels. Refer to Group SA, Section 2 on Jacking and Blocking of truck.




7. Disconnect and remove battery cables.


8. Disconnect and tag for reinstallation, all electrical wiring to drive line components. The main wiring harness will remain in the truck when the drive line is removed.




9. Disconnect and remove the air cleaner hoses and tube. The air cleaner can be left in place.




10. Disconnect the accelerator and choke cables at the carburetor. Lay the cables back where they will be out of the way of drive line removal.




11. Disconnect and remove gasoline fuel line or LPG hose.



12. Disconnect the transmission control cable and lay it back where it will not be in the way of drive line removal



13. Remove exhaust pipe.




14. Place a large drain pan which has a minimum capacity of 11 quarts (10.4 L) under the radiator and engine.

15. Remove the radiator cap.

⚠ WARNING STEAM

Do not remove the radiator cap when the radiator is hot. Steam from the radiator will cause severe burns.




Radiator Drain Cock


16. Open the radiator drain cock.
17. Remove the coolant drain plug from the engine.
18. After all coolant has been removed, replace the plug and drain cock.

NOTE


If the coolant is in good condition and has not been contaminated in removal, it can be saved for reuse. Otherwise dispose of it in the correct manner.




19. Remove coolant overflow hose.




20. Remove radiator hoses.




21. Remove the transmission cooling lines. Some fluid will be lost. Have a drain pan available. Do not reuse this fluid. Dispose of it in the prescribed manner.




22. Remove the radiator, transmission cooler and radiator shrouds.




23. Remove the engine fan.




24. Remove the alternator from the engine.




26. Remove the parking brake cable at the transmission.
Lay it back where it will be out of the way of drive line removal.




25. Remove the power steering/brake pump mounting bolts.
Then lay pump with drive pulley and hoses attached
and lay back on engine where it will be out of the way
of engine removal.



27. Unbolt the U-Joint at both ends and remove it.




28. Remove the center bolt from the engine mount at the transmission.



30. The engine and transmission are now ready to come out. No lifting eyes are provided on the Ford gasoline engine so it is necessary to rig a sling of nylon web lifting straps. Rig so that the front of the engine is on an up angle. Carefully work engine forward to extract parking brake assembly from truck frame.

31. Place engine and transmission assembly in an approved engine stand. Refer to Group 06 Section 1 for information on how to separate transmission from engine.

32. Reinstall engine and transmission in reverse order. Be sure to refer to "Critical fastener torques" in Group 40 Section 2.



Center engine mount bolts

29. Remove the center bolts from the front engine mounts.

TROUBLESHOOTING CHART

The following troubleshooting chart lists most of the usual complaints or troubles encountered in routine operation of all gasoline engines, with probable cause and troubleshooting procedure.

TROUBLESHOOTING (GAS and DIESEL):

Engine Will Not Start

Fuel System Trouble

- Foreign material in fuel
- Wrong Fuel
- Bad fuel pump
- Fuel shut off at tank
- A restriction in air filter system
- Bad injection nozzles
- A restriction in fuel filter
- Carburetor problem
- A restriction in choke linkage

Electrical System Trouble

- Dirty or loose battery connections
- Bad or loose wiring
- Weak battery
- Bad key switch
- Bad safety start switches
- Bad ignition system

Engine Does Not Run Evenly

Primary Engine Problem

- Wrong valve clearance
- A leak in cylinder head gasket
- Valves burned
- Worn or broken piston rings
- Low compression
- Wrong timing
- Coolant temperature below normal
- Engine temperature above normal

Fuel System Problem

- Low fuel supply
- A restriction in fuel lines or filters
- Bad fuel pump
- Bad injection pump
- Bad injection nozzles
- Exhaust system restriction Carburetor adjusted wrong
- Leaks in carburetor or intake manifold gaskets

Engine Does Not Run Evenly

Primary Engine Problem

- Worn camshaft lobes
- Weak valve springs
- Wrong valve clearance
- Burned valves
- Low compression
- Wrong timing
- Engine temperature above normal
- Bad governor

Fuel System Problem

- Air in fuel
- Bad injection nozzles
- Bad injection pump
- Water in fuel
- Wrong fuel mixture
- Bad fuel pump
- Bad carburetor

Electrical System Problem

- Wrong spark plugs
- Leaks in wiring
- Bad ignition system

A Loss of Power*Primary Engine Problem*

Broken cylinder head gasket
Worn camshaft lobes
Wrong valve clearance
Burned valves
Weak valve springs
Wrong timing
Low compression
Wrong oil viscosity
Coolant temperature wrong
Engine temperature above normal
Wrong throttle linkage
Governor not adjusted correctly

Fuel System Problem

A restriction in fuel filters
Wrong fuel
Bad injection pump
Bad injection nozzles
Bad fuel pump
A restriction in air cleaner
A restriction in exhaust system
Low pressure in intake manifold
A restriction in fuel line
Bad carburetor

Engine Temperature Above Normal*Primary Engine Problem*

Bad head gasket
Wrong timing
Crankcase oil level low
Low coolant level
Radiator dirty/Air flow restricted
Loose or broken fan belt
Bad thermostat
Restriction in cooling system
Bad radiator pressure cap
Bad water pump

Service Problem

Overload put on engine
Crankcase oil level low
Wrong fuel

Fuel System Problem

Fuel pressure above normal
Bad carburetor

Oil Consumption Above Normal*Primary Engine Problem*

A restriction in oil passage from valve cover
Worn valve guides or valve stems
Oil control rings worn or broken
Worn liners or pistons
Too much wear in piston rings
Ring restriction in grooves of piston
Restriction in piston oil return slots
Not enough piston ring tension
Piston ring gaps not at the correct spacing
Worn crankshaft thrust bearing
Too much clearance in main or connecting rod bearing
Front or rear crankshaft oil seal bad
Crankcase oil has a low viscosity
Oil pressure above normal
Oil level above normal

Service Problem

Crankcase oil has a low viscosity
Oil level above normal

Fuel System Problem

Restriction in air intake