

218 HYLAB 5 SERVICE MANUAL CONTENTS

0411

SECTION 0 General

How To Use This Manual, General Service Instructions, And Safety Procedures	SM00-000-001.00
Equipment Layout	ES00-03-0069.0R0S

SECTION 1 Upper Mechanism

Power Transmission System	ES01-01-0070.0R0S
Gears Maintenance Chart	ES01-01-2040.0R1S
Front And Rear Drum Shaft Structure And Outline	ES01-10-0034.0R0S
Front And Rear Drum Shaft Disassembly And Reassembly	ES01-10-6034.0R0S
Boom Hoist Drum Outline And Structure	ES01-15-0066.0R1S
Boom Hoist Drum Disassembly And Reassembly	ES01-15-6063.0R1S

Clutch (2-Cylinder Type)

Clutch Structure And Outline (2-Cylinder Type)	ES01-17-0034.0R0S
Clutch Maintenance Chart (2-Cylinder Type)	ES01-17-2034.0R0S
Clutch Troubleshooting (2-Cylinder Type)	ES01-17-4009.0R0S
Clutch Disassembly And Reassembly (2-Cylinder Type)	ES01-17-6034.0R0S

Swing Mechanism Maintenance Chart	ES01-29-2050.0R0S
Turntable Bearing Maintenance Chart	ES01-30-2030.4R0S
Turntable Bearing Inspection And Adjustment	ES01-30-5052.0R0S
Drum Maintenance Chart	ES01-42-2072.0R0S
Drum Indicator Troubleshooting	ES01-50-4001.1R0S

SECTION 2 Lower Mechanism

Lower General Explanation	ES02-01-0051.0R0S
Tread Drive Sprocket Maintenance Chart	ES02-05-2055.0R0S

Take-Up Idler

Take-Up Idler Maintenance Chart	ES02-07-2059.0R0S
Take-Up Idler Inspection And Oil Replacement	ES02-07-5046.0R0S
Take-Up Idler Disassembly And Reassembly	ES02-07-6053.0R1S

Carrier Roller Maintenance Chart	ES02-08-2054.0R0S
Track Roller Maintenance Chart	ES02-09-2048.0R0S

Track Shoe

Track Shoe Maintenance Chart	ES02-10-2053.0R0S
Track Shoe Inspection And Adjustment	ES02-10-5052.0R0S
Track Shoe Disassembly And Reassembly	ES02-10-6052.0R1S

Tread Member Maintenance Chart	ES02-12-2048.0R0S
Travel Reduction Gear Case Oil Inspection And Replacement	ES02-21-5050.0R0S

SECTION 3 Control System

Front And Rear Drum Brake Control Maintenance Chart	ES03-05-2074.0R0S
Front And Rear Drum Brakes Control Inspection And Adjustment	ES03-05-5068.0R0S
Front And Rear Drum Brakes Control Disassembly And Reassembly	ES03-05-6075.0R0S

SECTION 4 Hydraulic System

Hydraulic Circuit Outline	ES04-01-0082.0R0S
Hydraulic Circuit Pressure Adjustment	ES04-01-5083.0R0S

SECTION 5 Hydraulic Unit

Hydraulic Unit Equipment Layout ES05-01-0014.0R0S

Variable Delivery Pump

Variable Delivery Pump Outline And Structure ES05-02-0061.0R0S

Variable Delivery Pump Maintenance Chart ES05-02-2052.0R0S

Variable Delivery Pump Troubleshooting ES05-02-4009.0R0G

Variable Delivery Pump Disassembly And Reassembly ES05-02-6037.0R0S

Accumulator

Accumulator Structure ES05-05-0035.1R1S

Accumulator Inspection ES05-05-5032.1R1S

Accumulator Disassembly And Reassembly ES05-05-6046.1R1S

Front And Rear Winch Motor

Motor Structure And Outline ES05-09-0034.0R0S

Motor Maintenance Chart ES05-09-2025.0R0S

Motor Troubleshooting ES05-09-4011.0R0S

Motor Disassembly And Reassembly ES05-09-6034.0R0S

Boom Hoist Motor

Motor Structure And Outline ES05-11-0033.0R0S

Motor Maintenance Chart ES05-11-2025.0R0S

Motor Troubleshooting ES05-11-4002.0R0S

Motor Disassembly And Reassembly ES05-11-6029.0R0S

Rotating Joint Disassembly And Reassembly ES05-14-6029.2R3S

Brake Booster Structure And Working ES05-16-0016.0R1S

Brake Booster Disassembly And Reassembly ES05-16-6005.0R1S

Remote Control Valve Structure And Operation ES05-17-0032.0R0S

Remote Control Valve Troubleshooting ES05-17-4028.0R0S

Hydraulic Cylinder Troubleshooting ES05-23-4001.1R0S

Clutch Cylinder Disassembly And Reassembly (2-Cylinder Type, Right Hand) ES05-18-6034.0R0S

Automatic Brake Cylinder Disassembly And Reassembly ES05-19-6035.0R0S

Gantry Cylinder Disassembly And Reassembly ES05-24-6006.0R0S

Line Filter Inspection ES05-30-5061.1R0S

Line Filter Disassembly And Reassembly ES05-30-6061.1R0S

Return Filter Inspection ES05-32-5011.0R0S

Return Filter Disassembly And Reassembly ES05-32-6011.0R0S

8-Way Rotating Joint Inspection ES05-34-5014.0R1S

Swing Control Valve Structure And Operation ES05-35-0055.0R0S

3-Series Control Valve Structure And Operation ES05-37-0051.0R0S

4-Series Control Valve Structure And Operation ES05-38-0041.1R0S

6-Series Control Valve Structure And Operation ES05-40-0004.0R1S

Take-up Cylinder Disassembly And Reassembly ES05-57-6048.0R0S

Check Block Structure And Outline ES05-49-0013.0R1S

Counterweight Cylinder Disassembly And Reassembly ES05-59-6054.0R0S

SECTION 13 Electrical System

Electrical Diagram ES13-01-0067.0R0S


Electrical System Standardization ES13-01-9033.0R0S

Storage Battery Servicing And Installation ES13-04-5004.0R0S

SECTION 14 Tightening Torque Table

Bolt Tightening Torques ES14-02-0004.0R0S

1 Crane Main Body External View And Names




ECE0-27S

- For hydraulic equipment layout, refer to ES05-01-00△△ in this manual.
- For electric equipment layout, refer to ES13-01-00△△ in this manual.


2 Upper Machinery

2.1 Operating Equipment Inside Operator's Cab




ECE0-11S

2.2 General Equipment Of Upper Machinery



ECE0-28S

3 Lower Travel Machinery



The diagram illustrates a complex hydraulic system for a crane. Key components include:

- Hydraulic Oil Reservoir Tank:** The main source of hydraulic fluid.
- Engine:** The power source for the hydraulic pump.
- Swing Control Valve:** A multi-position valve (A, B, C, D, E, F, G, H) that directs flow to various actuators.
- Actuators:**
 - Booms:** Boom Hoist Drum, Third Drum, Rear Drum, and Front Drum, each equipped with a Flow Modulator (FM), Back Pressure Regulator (BR), and Check Valve (CV).
 - Tagline:** A separate actuator with its own FM, BR, and CV.
- Control Elements:** Various solenoid valves (SV) and pressure/flow control valves (FP, VP) are distributed throughout the system.
- Oil Cooler:** A component used to maintain the temperature of the hydraulic oil.
- Operator's Cab:** The central location from which the crane is operated, connected to the Swing Control Valve.

VP	Variable-Capacity Pump
FP	Fixed-Capacity Pump
VM	Variable-Capacity Motor
FM	Fixed-Capacity Motor
BV	Brake Valve
CV	Counterbalance Valve
CL	Clutch
BR	Brake
CYL	Cylinder
SV	Solenoid Valve

VP Variable-Capacity Pump
 FP Fixed-Capacity Pump
 VM Variable-Capacity Motor
 FM Fixed-Capacity Motor
 BV Brake Valve
 CV Counterbalance Valve
 CL Clutch
 BR Brake
 CYL Cylinder
 SV Solenoid Valve


Turntable Bearing
 Swing
 FM
 BR
 Rotary Center Joint
 To L.H. Retract CYL
 To L.H. Travel Device
 R.H. Travel Device
 BV
 FM
 R.H. Retract CYL
 6-Series Control Valve
 Lower Jack-up CYL
 4-Series Control Valve
 A : R.H. Travel
 B : Boom Hoist
 C : Rear Drum 1-Speed
 D : Front Drum 2-Speed
 4-Series Control Valve
 E : Third Drum
 F : L.H. Travel
 G : Rear Drum 2-Speed
 H : Front Drum 1-Speed

1 Front And Rear Drum Gears

Unit : mm(inches)

Item	Part Name	Number Of Teeth	#1	Allowable Back-lash	Treatment
1	Pinion Gear	3	78.3(3.083")	2.0(.079")	Replacement
2	Spur Gear	13	384.6(15.14")		

#1: Allowable Displacement Over A Given Number Of Teeth




ECE1-176S

2 Swing Gear

Unit : mm(inches)

Item	Part Name	Number Of Teeth	#1	Allowable Back-lash	Treatment
3	Swing Pinion Gear	3	93.924(3.70")	0.82(.032")	Replacement


#1: Allowable Displacement Over A Given Number Of Teeth



The hydraulic motor drives the drum via reduction gears. Separate motors and reduction gears are used for each drum.

1 Structure

The drum shaft mainly consists of a reduction gear case ④, drum shaft ⑧, clutch ⑨ and drum ⑩. The reduction gear ⑥ and drum shaft ⑧ are supported through bearings ⑦, ⑫ and ⑬. These are also clamped on the revolving frame with high tensile strength bolts. The clutch assembly is splined to the drum shaft. The drum is designed to rotate freely on the drum shaft with bearings ⑫. Spur gear lubrication oil is stored in the gear case, being an oil bath type.



CED0251Z-E

ECE1-139S

① Hydraulic Motor	⑥ Reduction Gear	⑪ Bearing Holder	⑯ Inspection Cover
② Pinion	⑦ Bearing	⑫ Bearing	
③ Level Plug	⑧ Drum Shaft	⑬ Bearing	
④ Reduction Gear Case	⑨ Clutch	⑭ Filler Cap	
⑤ Rotating Joint	⑩ Drum	⑮ Drain Cap	

Automatic brake and free fall operation

This unit possesses two modes of operation. One is an automatic brake function and the other is a free fall function. The automatic brake function constantly activates the clutch and thus the drum shaft and drum are connected. When the control lever is moved either hoist or lower, the brake is disengaged to rotate the drum. In the case of operation under free fall function, the automatic brake is disengaged at all time, and the control lever moved either to hoist or lower will activate the clutch to connect the drum shaft and drum. Thus the drum is rotated. When the control lever is placed in neutral, the drum becomes free with the clutch disengaged. Therefore, the braking operation by the brake pedal is required. For more details, refer to the operator's manual.

2 Inspection And Adjustment

Hydraulic motor Reduction gear case Rotating joint	Check for oil leakage.
All moving portions	Listen for any unusual noises and smell with load.
Pinion, Gear, Drum	Check for excessive wear, cracks and damage of teeth.
Reduction gear case	Check for lubricant oil level. With the check plug removed, the oil should be to the level of the plug hole. If below that level, add oil.
Mounting portions	Check for looseness and missing parts. If loosened or missing, replace and/or retighten with specified torque as required.

Note: After inspecting the above, disassemble or repair, as necessary.

2.1 Oil inspection of reduction gear case

- 1) Remove the level plug ③ and check the oil level. If the level is at the lower part of the level plug ③ hole, the oil is in proper quantity. If the oil level is too low, supply gear oil from the oil filler port.

- When oil overflows from the level plug ③ hole, the oil stands at the standard level.

Note: For proper oils, refer to the operator's manual.

2.2 Oil replacement of reduction gear case

Change oil yearly or 1000 hours of operations, whichever comes first.


- 1) Park the machine on level ground.
- 2) Engage the swing lock and shutdown the engine.
- 3) Wipe off the dirt from the drain cap ⑮, filler cap ⑭ and level plug ③ to prevent foreign material from entering.
- 4) Place a clean oil container under the drain cap ⑮.
- 5) Remove the drain cap ⑮, filler cap ⑭, level plug ③ and drain the oil.
Lubricant capacity: 6.2gal. (23.4lit.)

Note: Check foreign materials for the drained oil. If many foreign materials are found, check the case internal.


- 6) Screw the drain plug ⑮.
- 7) Fill the gear case with lubricant through the filler port up to the level at the lower part of the level plug ③.

Note: For proper lubricants, refer to the operator's manual.


- 8) Install the level plug ③ and the filler cap ⑭.



ECE1-134S



ECE1-130S




CED0251Z-E

ECE1-131S

- | | | | |
|-------------------|----------------|---------------|--------------------|
| ① Hydraulic Motor | ⑬ Spacer | ②⑤ Bearing | ③⑦ Bolt |
| ② Pinion | ⑭ O-Ring | ②⑥ Bolt | ③⑧ Washer |
| ③ Level Plug | ⑮ Back-Up Ring | ②⑦ Bolt | ③⑨ Gear Case Cover |
| ④ Gear Case | ⑯ Oil Seal | ②⑧ Bolt | ④⑩ Washer |
| ⑤ Rotating Joint | ⑰ Retainer | ②⑨ Drain Cap | ④① Bolt |
| ⑥ Spur Gear | ⑱ Retainer | ③⑩ Bolt | ④② Washer |
| ⑦ Bearing | ⑲ Oil Seal | ③① Washer | ④③ Bolt |
| ⑧ Shaft | ⑲ Spacer | ③② Level Plug | ④④ End Cap |
| ⑨ Filler Cap | ⑲ End Cover | ③③ Plug | ④⑤ Plug |
| ⑩ Drum | ⑲ Bearing | ③④ Bolt | |
| ⑪ Pillow Block | ⑲ Spacer | ③⑤ Washer | |
| ⑫ Sleeve | | ③⑥ Spacer | |

1 Disassembly Procedure



2 Preparation

- 1) Park the machine on level and stable ground.
- 2) Extend and set the side frame.

Note: Refer to the operator's manual.

- 3) Lower the boom.
- 4) Stop the engine.

CAUTION

Taking The Surroundings Into Consideration, Select A place Where Safe Operation Is Possible And Take Precautions Against Dangers. Particularly Avoid Slopes.

WARNING

Since The Component Parts Related To This Procedure Are Heavy, Handle Them Carefully Or Accidents May Result. Use A Supporting Base, Jack, Hoist And Others To Handle Them Efficiently. Check That The Hoist Capacity Is Sufficient.

3 Disassembly

3.1 Counterweight removal

Note: Refer to the operator's manual.


3.2 Gantry folding and removal

3.2.1 Gantry folding


Note: Refer to the operator's manual.

3.2.2 Gantry removal

- 1) Retract the strut by means of cylinder extension lever.
- 2) Stop the engine and operate the stay extension lever back and forth to release pressure in the cylinder.
- 3) Disconnect the hoses and pipes for the expansion cylinder. Attach the cap to the disconnected connector to prevent dusts from entering.



- 4) Supporting the backstay with a crane, remove the bolt, key plate and pin of the backstay from the revolving frame.
- 5) Remove the connect pins of the gantry strut.
- 6) Remove the gantry and strut as an assembly.



3.3 Right house cover removal

WARNING

Do Not Place Yourself Under The Hanging House. When Removing The House From The Main Body Of The Machine, Never Place Yourself Between The House And The Main Body.

- 1) Remove the house cover.