

# 348 HYLAB 5 SERVICE MANUAL CONTENTS

WET0075-102 0606R0

## SECTION 0 General

How To Use This Manual, General Service Instructions, And Safety Procedures .....	SM00-000-001.00
Introduction .....	ES00-00-0007.0R0S
Equipment Layout .....	ES00-03-0073.0R0S

## SECTION 1 Upper Mechanism

Power Transmission System .....	ES01-01-0082.0R0S
Front And Rear Drum Shaft Structure And Outline .....	ES01-10-0070.0R0S
Front And Rear Drum Shaft Disassembly And Reassembly .....	ES01-10-6065.0R0S
Boom Hoist Drum Structure And Outline .....	ES01-15-0071.0R0S
Clutch Structure And Outline .....	ES01-17-0056.0R1S
Clutch Maintenance Chart .....	ES01-17-2075.1R0S
Clutch Troubleshooting .....	ES01-17-4048.1R0S
Clutch Disassembly And Reassembly .....	ES01-17-6052.0R2S
Swing Mechanism Structure And Outline .....	ES01-29-0019.0R0S
Swing Mechanism Maintenance Chart .....	ES01-29-2052.0R0S
Turntable Bearing Maintenance Chart .....	ES01-30-2030.6R0S
Turntable Bearing Inspection And Adjustment .....	ES01-30-5054.0R0S
Power Divider (Gear Box) Structure And Oil Inspection .....	ES01-40-0004.0R0S
Power Divider (Gear Box) Maintenance Chart .....	ES01-40-2064.0R0S
Drum Maintenance Chart .....	ES01-42-2074.0R0S
Drum Indicator Troubleshooting .....	ES01-50-4001.1R0S

## SECTION 2 Lower Mechanism

Lower General Explanation .....	ES02-01-0057.0R0S
Tread Drive Sprocket Maintenance Chart .....	ES02-05-2058.0R0S
Take-Up Idler Maintenance Chart .....	ES02-07-2062.0R0S
Take-Up Idler Inspection And Oil Replacement .....	ES02-07-5051.0R0S
Take-Up Idler Disassembly And Reassembly .....	ES02-07-6058.0R0S
Carrier Roller Maintenance Chart .....	ES02-08-2056.0R0S
Track Roller Maintenance Chart .....	ES02-09-2054.0R0S
Track Shoe Maintenance Chart .....	ES02-10-2054.0R0S
Track Shoe Inspection And Adjustment .....	ES02-10-5057.0R0S
Track Shoe Disassembly And Reassembly .....	ES02-10-6057.0R0S
Side Frame And Guide Shoe Maintenance Chart .....	ES02-12-2050.0R0S
Travel Reduction Gear Case Structure And Oil Inspection .....	ES02-21-5055.0R0S

## SECTION 3 Control System

Front And Rear Drum Brake Control Maintenance Chart .....	ES03-05-2071.0R0S
Front And Rear Drum Brake Control Disassembly And Reassembly .....	ES03-05-6072.0R0S
Front And Rear Drum Pawl Lock Maintenance Chart .....	ES03-10-2067.0R0S
Boom Hoist Drum Pawl Lock Maintenance Chart .....	ES03-12-2062.0R0S

## SECTION 4 Hydraulic System

Hydraulic Circuit .....	ES04-01-0086.0R0S
Hydraulic Circuit Pressure Adjustment .....	ES04-01-5081.0R0S

## SECTION 5 Hydraulic Unit

Hydraulic Unit Equipment Layout .....	ES05-01-0018.0R0S
Variable Delivery Pump Outline And Structure .....	ES05-02-0067.0R0S
Variable Delivery Pump Maintenance Chart .....	ES05-02-2053.0R0S

# 348 HYLAB 5 SERVICE MANUAL CONTENTS

WET0075-102 0606R0

Variable Delivery Pump Troubleshooting .....	ES05-02-4009.0R0S
Variable Delivery Pump Disassembly And Reassembly .....	ES05-02-6040.0R0S
Gear Pump .....	ES05-03-0016.0R0S
Gear Pump Troubleshooting .....	ES05-03-4052.0R0S
Accumulator Structure .....	ES05-05-0035.1R1S
Accumulator Inspection .....	ES05-05-5032.1R1S
Accumulator Disassembly And Reassembly .....	ES05-05-6046.1R1S
Front And Rear Drum Motor Structure And Outline .....	ES05-09-0048.0R0S
Front And Rear Drum Motor Troubleshooting .....	ES05-09-4025.0R0S
Boom Hoist Motor Structure And Outline .....	ES05-11-0032.0R0S
Swing Motor Structure And Outline .....	ES05-12-0013.0R0S
Travel Motor Structure And Outline .....	ES05-13-0052.0R0S
Rotating Joint Disassembly And Reassembly .....	ES05-14-6029.2R3S
Remote Control Valve Structure And Operation .....	ES05-17-0033.0R0S
Remote Control Valve Troubleshooting .....	ES05-17-4028.0R0S
Clutch Cylinder Disassembly And Reassembly (Front And Rear Drum) .....	ES05-18-6075.0R0S
Hydraulic Cylinder Troubleshooting .....	ES05-23-4001.1R0S
Tread Cylinder Disassembly And Reassembly .....	ES05-25-6002.0R0S
Boom Foot Pin Cylinder Disassembly And Reassembly .....	ES05-27-6053.0R0S
Rotary Center Joint Disassembly And Reassembly .....	ES05-34-6015.0R0S
Swing Control Valve Structure And Operation .....	ES05-35-0056.0R0S
1-Series Control Valve Structure And Operation .....	ES05-36-0036.0R0S
3-Series Control Valve Structure And Operation .....	ES05-37-0052.0R0S
4-Series Control Valve Structure And Operation .....	ES05-38-0044.0R0S
8-Series Control Valve .....	ES05-40-0005.0R0S
Take-Up Cylinder Disassembly And Reassembly .....	ES05-57-6051.0R0S
Counterweight Cylinder Disassembly And Reassembly .....	ES05-59-6055.0R0S
Counterweight Pin Cylinder Disassembly And Reassembly .....	ES05-60-6001.0R0S
Pawl Lock Cylinder Disassembly And Reassembly .....	ES05-61-6001.0R0S
Jack Cylinder Disassembly And Reassembly .....	ES05-62-6001.0R0S
Live Mast Flip Cylinder Disassembly And Reassembly .....	ES05-63-6001.0R0S
Operator's Cab Tilt Cylinder Disassembly And Reassembly .....	ES05-64-6001.0R0S

## SECTION 13 Electrical System

Electric Circuit Diagram .....	ES13-01-0072.0R0S
Electrical System Standardization .....	ES13-01-9033.0R0S
Storage Battery Servicing And Installation .....	ES13-04-5004.0R0S
Electric Equipment Layout, Wiring And Wire Harness .....	ES13-10-0008.0R0S

## SECTION 14 Tightening Torque Table

Bolt Tightening Torques .....	ES14-02-0004.0R0S
-------------------------------	-------------------

**348 HYLAB 5 Series - Master Keysheet (Boom)**  
(L9 Prefix On Crane Serial Number)**AREA 00 GENERAL INFORMATION**

\*\*\*\*\*

SM00- 000- 000.00 Service Manual General Usage &amp; Instructions

**AREA 06 UPPER ENGINE**

\*\*\*\*\*

SM06- 044- 002.00 Generator &amp; Light Plant Schematic Diagram

**AREA 07 HYDRAULIC POWER SUPPLY**

\*\*\*\*\*

SM07- 000- 000.00 Hydraulic Schematic Diagram Symbol Legend

SM07- 008- 067.00 Foot Control Valve, Recondition (Boom Hoist)

SM07- 008- 174.00 Boom Hoist Foot Pedal Control Valve, R &amp; I

SM07- 008- 175.00 Boom Hoist Control Lever Valve, R &amp; I

SM07- 018- 001.00 Hydraulic System Tube Fittings

**AREA 09 TUBULAR BOOM, FLY, & JIB**

\*\*\*\*\*

SM09- 001- 002.00 Repairing Damaged Tubular Booms, Flys, &amp; Jibs

SM09- 002- 006.00 Live Mast Self Assembly Cylinder, Recondition (Seabee)

SM09- 002- 013.00 Boom Self Assembly Cylinder Relief Valve, Recondition

SM09- 002- 014.00 Boom Self Assembly Cylinder, R &amp; I

SM09- 009- 002.00 Hydraulic Backstop Cylinder, R &amp; I

SM09- 009- 003.00 Hydraulic Backstop Cylinder, Recondition (Generation 1)

SM09- 009- 004.00 Hydraulic Backstop Valve Block, R &amp; I

SM09- 009- 005.00 Hydraulic Backstop Valve Block, Illustrated

SM09- 009- 006.00 Hydraulic Backstop Cylinder, Recondition (Generation 2)

**AREA 18 SPECIAL ATTACHMENTS**

\*\*\*\*\*

SM18- 000- 001.00 Capscrew Torques

SM18- 000- 002.00 Bearing, Gear, Shaft, &amp; Housing Inspection

SM18- 000- 003.00 Crane System Schematics



## How To Use This Manual, General Service Instructions, And Safety Procedures

The following information is provided to help guide the user of this manual. An explanation of how this manual is organized, as well as general information and safety considerations which should be understood when performing any service or maintenance procedure, is given. This information is general in nature and should supplement any of the specific procedures in this manual along with a constant awareness of safety and common sense.

### How To Use This Manual

This Service Manual is a collection of written procedures which are used to service and maintain a specific crane model. The index, which is called a “Keysheet”, is used to organize the procedures within this manual and serve as a Table Of Contents as well. Each procedure, in this manual, is written so that it can stand alone and typically covers only one procedure. Procedures are given a numerical designation, or “SM Code” Number, (Example: ES01–01–0032.0R for HSC/SCM items or SM01–005–034.00 for LBCE items) which is unique to that procedure and that procedure only. The following is a listing of the general area definitions which are designated by the first digits in the SM Code Number sequence:

### General Area Descriptions - HSC/SCM Items

ES00–	Section – 0	General
ES01–	Section – 1	Upper Mechanism
ES02–	Section – 2	Lower Mechanism
ES03–	Section – 3	Control System
ES04–	Section – 4	Hydraulic System
ES05–	Section – 5	Hydraulic Unit
ES06–	Section – 6	Gantry
ES07–	Section – 7	Crane Attachment
ES13–	Section – 13	Electrical System
ES14–	Section – 14	Tightening Torque Table

### General Area Descriptions - LBCE Items

SM01 –	Rubber Tire Lower
SM02 –	Crawler Lower
SM03 –	Upper Revolving Frame & Machinery
SM04 –	Vertical Shafts
SM05 –	Horizontal Shafts
SM06 –	Upper Engine
SM07 –	Hydraulic Power Supply
SM08 –	Angle Boom
SM09 –	Tubular Boom
SM10 –	Tagline Winder
SM11 –	Fairleader
SM12 –	Shovel Attachment
SM13 –	Trench Hoe, Logger & Scraper Attachment & Prop Handler
SM14 –	Cab & House Assembly
SM15 –	Rotascope Attachment (Discontinued)
SM16 –	Wire Rope Requirements
SM17 –	Hydraulic Boom And Attachments
SM18 –	Special Attachments
SM19 –	Diesel Pile Hammer (Discontinued)
SM20 –	Tower, Climbing Assembly, Traveling Base & Gantry (Discontinued)
SM21 –	Log Skidder (Discontinued)
SM22 –	Hydraulic Hammer (Discontinued)

The procedures in this manual are collated by SM Code Number sequence. Use the Keysheet in the front of this manual, the general area descriptions shown previously, and the SM Code title shown on the Keysheet to find the specific procedure required to service the crane.

Throughout this manual, reference is made to the left, right, front, and rear, pertaining to directions and locations. These reference directions are relative to the operator, sitting in the operator's seat, with the upper directly over the front of the lower, unless otherwise stated. (Crawler mounted cranes: upper over the front of the crane with travel motors to the rear.)

Danger, warning, and caution captions as well as special notes are used throughout this manual and on the crane to emphasize important and critical instructions. **If any instruction, caution, warning, or danger labels, decals, or plates become lost, damaged, or unreadable, they must be replaced.** Information contained on such labels, decals, and plates is important and failure to follow the information they contain could result in an accident. Replacement labels, decals, and plates can be ordered through a Link-Belt Distributor. For the purpose of this manual, danger, warning, and caution captions and notes are defined as follows:



Figure 1  
Keep hands and tools clear of moving parts.






Figure 2  
Diesel Exhaust Fumes.



## NOTES

Note: An operating procedure step, condition, etc. which is essential in order for the process to be completed properly.




This symbol may appear in manuals or on a label on the crane to alert personnel that additional instructions are included in the crane Operator's Manual.


## Service Safety And Set Up Guidelines

The following is a list of safety and set up considerations which may apply to any service or maintenance procedure. Review the entire list and understand the type of things you must consider to perform a safe service procedure and then apply these guidelines to each specific service or maintenance procedure.


### Service Safety

1. Read and understand the service or maintenance procedure to be performed before beginning work. By reading the procedure ahead of time, you can be sure to have the replacement parts and tools on hand that are required to complete the job.
2. Wear protective gear to prevent injury; hard hat, safety glasses, mask, gloves, steel toed shoes, etc.
3. First aid supplies and a fire extinguisher should be on the job site to assist in an unexpected situation. The location of these items should be known to all as well as access to a telephone for emergencies.
4. Work in a clean, dry, firm, level area whenever possible. Choosing the correct work site can make a big difference on how well the job goes.
5. Use caution around flammable materials. Be aware of all the materials in the work area which are a threat. Also make others aware of volatile materials; post signs if necessary.






6. Release all trapped pressure in air and hydraulic circuits before disconnecting any line or component. Shutdown the crane, exhaust all pressure from the crane's air reservoir(s) and work the hydraulic control levers back and forth before servicing the crane.
7. Do not disconnect any hydraulic line from a crane which has its attachment in the air. Trapped pressure may be all that is suspending it. Disconnecting a line could release the trapped pressure, causing the attachment to fall. Lower the attachment to the ground or on to its rest before servicing the crane.
8. Do not work on a crane which is in motion. Fans, belts, gear trains, etc. can catch an unexpected person and quickly dismember them.
9. Do not climb on the attachment or other hard to reach areas. If the steps and/or ladders which are installed on the crane do not provide adequate access to the area of the crane which needs servicing, use a step ladder or other approved device.
10. Pinch points exist between the upper and lower frames. Death or dismemberment may result from personnel caught in these points. Learn where these pinch points are and stay clear of the rotating upper frame.
11. If working in a confined area, always provide adequate ventilation when running the engine(s), using toxic solvents, welding, or any other operation which contaminates the fresh air supply.
12. Post a sign in the operator's cab to alert others that the crane is under service. Starting the crane while it is being serviced could severely injure someone. Crane damage could also occur if systems are operated prematurely. Imagine starting the engine(s) before the oil is replaced!



13. Secure access panels, doors, and machinery hoods when in the open position to ensure they do not fall or slam shut due to wind or accidental disruption.
14. Crane parts may be heavy. Always use an appropriate lifting device to support work. Do not attempt to lift an object without knowing its weight. Get help if necessary.
15. Always use a safety rim cage when inflating or deflating tires. Worn or misassembled parts can "explode" from the assembly causing serious injury. Use a safety rim cage, clip on air chuck, and stand aside when inflating or deflating tires.

## Crane Set Up And Disassembly

1. Properly park the crane as described in the Operator's Manual. Park the crane in an area which provides the most comfortable working conditions. However, do not park the crane where it will be an obstruction or an intrusion to traffic, coworkers, or to the public. Keep in mind that a major service procedure, or a repair part which requires a long lead time, could have the crane disabled for an extended period of time.
2. Keep in mind the mess which is sometimes caused by a crane under repair. Oil or other fluid leaks should be contained or prevented. Consider your responsibility of maintaining a safe clean work area and a healthy environment for all.
3. If the crane is equipped with outriggers, it may be safer as well as an advantage to raise and level the crane on outriggers to provide better safety and easier access to areas underneath. Do not work under a crane that is improperly supported.
4. Shutdown the engine(s) per the instructions given in the Operator's Manual.
5. Post a sign in the operator's cab to alert others that the crane is being serviced.



**Figure 5**  
Allow engine to cool before removing the radiator cap.

6. Engines, transmissions, hydraulic systems, etc. generate extreme heat during operation. Temperatures can reach levels which may cause serious burns. Allow the crane to cool before attempting to service it.

### **WARNING**

**Engine coolant is hot. Failure to allow engine(s) to sufficiently cool before draining coolant could result in severe burns or other personal injury. Allow the engine(s) and radiator(s) to cool before draining coolant from the radiator(s).**

7. Pressure is generated inside the engine's cooling system due to the heat transfer process from the engine(s) to the radiator(s). Do not attempt to open or drain the radiator(s) until it/they has/have had sufficient time to cool. Disconnecting hoses before the engine(s) and radiator(s) has/have cooled is even more dangerous. Wait until the engine(s) and radiator(s) has/have cooled and then drain the radiator(s) before disconnecting any hoses. Properly store or dispose of used coolant.

### **WARNING**

**Solvents and cleaning solutions can be hazardous. Serious personal injury may result from misuse of these products. Read and follow all the manufacturer's recommendations concerning solvents and cleaning solutions.**

8. Thoroughly clean the area of the crane which is to be serviced. Dirt or other contamination could enter the hydraulic, air, lubricating systems, etc. and cause immediate and/or long term problems.

Cleaning the service area not only prevents contamination problems but it also makes working on the crane easier and sometimes problems are more recognizable.

9. Before beginning any removal or disassembly procedure, take a moment to observe critical features of the assembly which may greatly simplify the installation or assembly process. Label electrical, hydraulic, air, or other connections. Index mark pump, motor, and valve sections. Lightly spray paint or count the threads of adjustment screws. Simple steps such as these can minimize the effort needed to put the crane back in service.

### **WARNING**

**Hydraulic oil is under pressure and may be hot. A sudden release of hot oil could cause severe burns and/or other serious injury. Shutdown the engine(s) and exhaust all trapped hydraulic pressure from the system before removing any line or component.**

10. Hydraulic systems, while operating, are under high pressure. Even after the crane is shutdown these pressures can remain trapped in the hydraulic lines and system components. Some hydraulic systems utilize an air pressurized reservoir which maintains pressure on the system after the crane is shutdown. It is critical that all residual pressure, which is trapped in the system, be neutralized before disconnecting any line or hydraulic component. Use the following techniques to exhaust trapped hydraulic pressure from the system:
- Lower the attachment to the boom rest, onto blocking, or onto the ground and shutdown the engine(s).
  - Open the drain valves on the air system reservoir(s), if equipped, to bleed the air system pressure.
  - Relieve any residual or precharge pressure by pushing the button on the pressure relief valve, on the hydraulic reservoir, if equipped. Otherwise, loosen the filler cap 1/4 turn.
  - Turn the ignition switch to the **ON POSITION**, but **DO NOT START THE ENGINE**.
  - Operate the steering control(s) back and forth repeatedly until steering becomes hard. (On cranes equipped with emergency steering system, it will take several rotations of steering wheel before steering becomes hard.)
  - Work the crane control levers and outrigger switches, if equipped, back and forth several times.
  - Turn ignition switch to the **OFF POSITION**.

- h. Check that all control levers are in the neutral position and move the gate lock lever, if equipped, to the "STOP" position.
- i. When pressure is fully relieved, close the drain valves on the air system reservoir(s), if equipped.



## WARNING

**Air lines may contain high pressure. Opening lines and fittings before relieving air pressure may result in serious injury. Shutdown the engine(s) and drain the air system reservoir(s) before opening any line or fitting.**

11. Air system circuits, like hydraulic circuits, may contain high pressures also. Although the threat of a hot working fluid does not exist, highly pressurized lines and components can possibly "fly off" if lines are disconnected before the system pressure is relieved. Open the drain valve on the air system reservoir(s) to exhaust system pressure before working on the crane.




## WARNING

**Use care not to cause sparks at the battery terminals while disconnecting or connecting the battery. Battery gasses are volatile and could be ignited by a spark or flame causing the battery to explode. Keep the area around the battery well ventilated and disconnect the negative side of the battery first, with the ignition switch "OFF", to minimize hazard.**

**Battery posts, terminals, and related accessories contain lead and lead compounds. Eating or smoking with lead residue on hands may cause lead poisoning. Wash hands after handling lead products.**

12. When working on electrical circuits, disconnect the battery to minimize shock, burn, spark, or other hazard. When disconnecting the battery, confirm that the ignition switch is in the "OFF" position. Disconnect the negative side of the battery first to minimize the potential for sparks at the battery. Battery gases which are exposed to such sparks, could cause an explosion. Likewise when connecting the battery, confirm that the ignition switch is in the "OFF" position and install the positive cable(s) first, and the negative connection(s) last.
13. It is a good practice when disassembling hydraulic components to lay the parts out in the order that they were disassembled. Keeping the parts in this order during disassembly, cleaning, and inspection will aid in the assembly process.



**Figure 6**

**Do not use an open flame near the battery.**

## Welding


1. When making repairs which require welding, disconnect any electronic equipment (such as rated capacity limiters and engine computers) to prevent damage to them. Use the battery disconnect switch(es), if equipped.
2. Be aware of systems adjacent to areas being welded. Residual heat from the welding process could cause damage to other components. Heat may also vaporize materials which may become toxic or volatile.
3. Remove paint from areas to be welded to prevent toxic fumes.
4. The ground connection should be within 3 feet (1 m) of the welded parts.
5. Connect the ground to the lower, if welding on the lower, or to the upper if welding on the upper. Electrical current through the turntable bearing could cause an arc which could damage it.
6. Do not position the ground connection where seals or bearing, as in transmissions or valves, will be between it and the welded parts.
7. Remove any flammable materials from the area.
8. Use the appropriate setting on the welder for the size of the welding operation. Do not use more than 200 Volts continuously.

## Cleaning And Inspection



## WARNING

**Solvents and cleaning solutions can be hazardous. Serious personal injury may result from misuse of these products. Read and follow all the manufacturer's recommendations concerning solvents and cleaning solutions.**



**Figure 7**  
**Proper Disposal Is Important.**

1. All components should be thoroughly cleaned with an approved cleaning solvent, air dried and carefully inspected for damage, wear, and/or corrosion.
2. All Loctite<sup>®</sup> or other sealant residue should be removed from threads of hardware and parts that are going to be reused.
3. All "soft parts", such as seals, gaskets, back up rings, and o-rings, should be replaced.
4. Replacement of bearings and bushings is generally a good preventive maintenance measure. Even though a bearing or bushing seems to be intact and is functioning properly, its life span is limited. Replacing a simple bearing or bushing while the opportunity is at hand could save a complete component failure later.
5. In the event of major defects, contact factory personnel for directions whether to repair or replace any major component.

### Crane Assembly

1. Loosely assemble parts to ensure all parts are in place and fasteners started before beginning torquing procedure. Always use a cross torquing sequence to ensure even and uniform installation.



### WARNING

Lubricants, sealants, joint and thread locking compounds, etc. can be hazardous. Serious personal injury may result from misuse of these products. Read and follow all manufacturer's recommendations concerning these products.

2. Unless otherwise stated, torque all fasteners per the instructions given in SM Code Area 18-000.
3. When installing hydraulic hoses, lines, and fittings, use two wrenches to ensure the hoses and lines are not twisted. One wrench must be on the male fitting, the other wrench on the female fitting.
4. Unless otherwise stated, torque all hydraulic fittings per the instructions given in SM Code Area 07-018.
5. Check all fluid levels before returning the crane to service; hydraulic reservoir oil level, transmission fluid level, engine(s) oil level, etc. Add oil as required. See Operator's Manual and/or engine(s) manufacturer's manual(s) for correct type of fluids and procedures.
6. Always replace guards, grilles, and other types of protective shields. Also, confirm that any systems which were disconnected such as load indicating systems, anti-two block devices, control cables, etc. are functioning properly before returning the crane to service.
7. Start the appropriate engine and let it idle for five minutes. Inspect the connections on the hydraulic, air, transmission, etc. lines for leaks. Repair if needed.
8. Check that all hydraulic, air, and electrical functions are operating normally before returning the crane to service.
9. After crane is assembled, refer to the Operator's Manual for any periodic type of adjustments which may have been affected by the service procedure.
10. Properly dispose of any used oils, solvents, cleaners, etc.

This manual is used as the guidance "which contains the procedure to diagnose the machine, judge normality/abnormality, isolate the troubled area and carry out repairs soon".

The service life of the machine differs largely depending on the operation method and working conditions. To maintain the initial performance longer, daily operation, inspection and adjustment are very important.

Also, to prevent any trouble, not only proper operation but also ordinary maintenance, inspection and adjustment become important. If any trouble occurs, immediately diagnose the trouble and repair it.

To always maintain the machine under optimal conditions, read through this manual before the maintenance work and use this manual as a helpful guide.


## **WARNING**

- If This Machine Is Not Properly Operated, Serious Injury And Damaging Accidents To The Machine May Result. Read And Understand The Contents Of Operator's Manual Thoroughly Before Operating The Machine. Leave This Manual In A Convenient Place For The Operator Or Maintenance Person Of This Machine And Read It Repeatedly.
- This Machine Has Been Designed Manufactured To Meet The Regulations And Standards Of The Country Of Destination. If This Machine Is Purchased From Another Country Or Is To Be Used In Another Country, There May Be Differences In Required Safety Devices Or Specifications For Safety. Please Contact Us Or Our Distributors If You Have Questions About Meeting The Regulations And Standards For The Country In Which The Machine Will Be Used.

- The material contained in this manual presupposes use by service engineers.
- The explanations described in this manual may differ from the machine delivered. For delivered specifications, refer to the specifications or the sales contract.
- The page sheet system is adopted. The components are divided mainly into main categories and every system is described.
- This manual is totally devoted to information necessary for machine repair: general information pertaining to operation, functional descriptions and safety measures are outside the range of this manual.
- The areas which require special care during working are described and clarified with "DANGER", "WARNING", or "CAUTION". Make efforts to observe safe work to prevent accidents and machine damage.
- Information concerning the engine, carrier and accessories, which can be obtained from the maintenance manuals provided by the manufacturer, in possession of the dealers, or purchased from the manufacturer, is not duplicated in this manual. Refer to those manuals for further information.
- Since the maintenance/inspection, adjustment, lubrication and others which the user and operator must observe regularly (daily, monthly, yearly and periodically) are described in the operator's manual, they are omitted from this manual. Recommended to use the operator's manual together with this manual.
- Recommended to use the parts manual together with this manual.
- If the manual is badly damaged or lost, order it from us or our distributor's.
- When ordering parts, refer to separate "Parts Manual."
- If there is any thing your don't understand, contact your nearest distributor.




## 1 Crane Main Body External View And Names



- For hydraulic equipment layout, refer to ES05-01-00--in this manual.
- For electric equipment layout, refer to ES13-10-00--in this manual.

## 2 Upper Machinery

### 2.1 Operating Equipment Inside Operator's Cab



## 2.2 General Equipment Of Upper Machinery

