

Section-0 General**Serial No.**

Equipment Layout -----	ES00-03-0040.0R0	0011-
------------------------	------------------	-------

Section-1 Upper Mechanism

Power Transmission System -----	ES01-01-0040.0R0	0011-
Front And Rear Drum Shaft Structure And Outline -----	ES01-10-0040.0R0	0011-
Front And Rear Drum Shaft Maintenance Chart -----	ES01-10-2040.0R0	0011-
Front And Rear Drum Shaft Disassembly And Reassembly -----	ES01-10-6040.0R0	0011-
Third Drum Shaft Structure And Outline -----	ES01-12-0032.0R0	0011-
Third Drum Shaft Maintenance Chart -----	ES01-12-2032.0R0	0011-
Third Drum Shaft Disassembly And Reassembly -----	ES01-12-6032.0R0	0011-
Boom Hoist Drum Structure And Outline -----	ES01-15-0009.0R0	0011-
Boom Hoist Drum Disassembly And Reassembly -----	ES01-15-6040.0R0	0011-
Clutch Structure And Outline -----	ES01-17-0040.0R0	0011-
Clutch Structure And Outline -----	ES01-17-0040.1R0	0011-
Clutch Maintenance Chart (2-Cylinder Type) -----	ES01-17-2025.1R0	0011-
Clutch Maintenance Chart (1-Cylinder Type) -----	ES01-17-2040.0R0	0011-
Clutch Maintenance Chart (1-Cylinder Type) -----	ES01-17-2040.1R0	0011-
Clutch Troubleshooting (2-Cylinder Type) -----	ES01-17-4009.0R0	0011-
Clutch Troubleshooting (1-Cylinder Type) -----	ES01-17-4023.0R0	0011-
Clutch Disassembly And Reassembly (2-Cylinder Type) -----	ES01-17-6023.0R0	0011-
Clutch Disassembly And Reassembly (1-Cylinder Type) -----	ES01-17-6040.0R0	0011-
Clutch Disassembly And Reassembly (1-Cylinder Type) -----	ES01-17-6040.1R0	0011-
Turntable Bearing Maintenance Chart -----	ES01-30-2030.0R1	0011-
Turntable Bearing Disassembly And Reassembly -----	ES01-30-6040.0R0	0011-
Power Divider (Pump Splitter) Maintenance Chart -----	ES01-40-2032.0R0	0011-
Pump Splitter Disassembly And Reassembly -----	ES01-40-6040.0R0	0011-

Section-2 Lower Mechanism

Lower General Explanation -----	ES02-01-0032.0R0	0011-
Tread Drive Sprocket Maintenance Chart -----	ES02-05-2032.0R0	0011-
Take-Up Idler Maintenance Chart -----	ES02-07-2032.0R0	0011-
Take-Up Idler Inspection And Oil Replacement -----	ES02-07-5040.0R0	0011-
Take-Up Idler Disassembly And Reassembly -----	ES02-07-6032.0R0	0011-
Carrier Roller Maintenance Chart -----	ES02-08-2032.0R0	0011-
Carrier Roller Disassembly And Reassembly -----	ES02-08-6032.0R0	0011-
Track Roller Maintenance Chart -----	ES02-09-2032.0R0	0011-
Track Roller Disassembly And Reassembly -----	ES02-09-6032.0R0	0011-
Track Shoe Maintenance Chart -----	ES02-10-2032.0R0	0011-

Track Shoe Inspection And Adjustment -----	ES02-10-5032.0R0	0011-
Track Shoe Disassembly And Reassembly -----	ES02-10-6032.0R0	0011-
Travel Reduction Gear Maintenance Chart -----	ES02-21-2032.0R0	0011-
Travel Reduction Gear And Gear Case Oil Inspection And Replacement -----	ES02-21-5032.0R0	0011-
Travel Reduction Gear And Gear Case Disassembly And Reassembly -----	ES02-21-6032.0R0	0011-

Section-3 Control System

Front And Rear Drum Brakes Control Maintenance Chart -----	ES03-05-2040.0R0	0011-
Front And Rear Drum Brakes Control Inspection And Adjustment -----	ES03-05-5040.0R0	0011-
Front And Rear Drum Brakes Control Disassembly And Reassembly -----	ES03-05-6040.0R0	0011-
Third Drum Brake Control Maintenance Chart -----	ES03-07-2032.0R0	0011-
Third Drum Brake Control Inspection And Adjustment -----	ES03-07-5032.0R0	0011-
Third Drum Brake Control Disassembly And Reassembly -----	ES03-07-6032.0R0	0011-

Section-4 Hydraulic System

Hydraulic Circuit Outline -----	ES04-01-0040.0R0	0011-0028
Hydraulic Circuit Outline -----	ES04-01-0040.1R0	0029-
Hydraulic Circuit Pressure Adjustment -----	ES04-01-5040.0R0	0011-0028
Hydraulic Circuit Pressure Adjustment -----	ES04-01-5040.1R0	0029-

Section-5 Hydraulic Unit

Variable Delivery Pump Outline And Structure -----	ES05-02-0032.0R0	0011-
Variable Delivery Pump Maintenance Chart -----	ES05-02-2032.0R0	0011-
Variable Delivery Pump Troubleshooting -----	ES05-02-4009.0R0	0011-
Variable Delivery Pump Disassembly And Reassembly -----	ES05-02-6032.0R0	0011-
Gear Pump (3-Series Type) Disassembly And Reassembly -----	ES05-03-6034.0R0	0011-
Accumulator Structure And Working -----	ES05-05-0009.1R0	0011-0028
Accumulator Structure And Working -----	ES05-05-0009.2R0	0029-
Accumulator Inspection And Adjustment -----	ES05-05-5009.1R0	0011-
Accumulator Disassembly And Reassembly -----	ES05-05-6009.2R0	0011-
Rotating Joint Disassembly And Reassembly -----	ES05-14-6029.0R0	0011-0028
Rotating Joint Disassembly And Reassembly -----	ES05-14-6029.1R0	0029-
Brake Booster Function And Operation -----	ES05-16-0011.0R0	0011-
Remote Control Valve Structure And Operation -----	ES05-17-0009.0R0	0011-0028
Remote Control Valve Structure And Operation -----	ES05-17-0009.1R0	0029-
Remote Control Valve Troubleshooting -----	ES05-17-4009.0R0	0011-
Remote Control Valve Disassembly And Reassembly -----	ES05-17-6009.0R0	0011-0028
Remote Control Valve Disassembly And Reassembly -----	ES05-17-6009.1R0	0029-
Clutch Cylinder Disassembly And Reassembly (2-Cylinder Type, Right Hand) ---	ES05-18-6003.1R0	0011-

LS-208H SHOP MANUAL CONTENTS

WET0011-00

Clutch Cylinder Disassembly And Reassembly (1-Cylinder Type) -----	ES05-18-6030.0R0	0011-
Automatic Brake Cylinder Disassembly And Reassembly -----	ES05-19-6032.0R0	0011-
Retract Cylinder Disassembly And Reassembly -----	ES05-23-6032.0R0	0011-
Line Filter Inspection -----	ES05-30-5011.0R0	0011-
Line Filter Disassembly And Reassembly -----	ES05-30-6011.0R0	0011-
Return Filter Inspection -----	ES05-32-5011.0R0	0011-
Return Filter Disassembly And Reassembly -----	ES05-32-6011.0R0	0011-
8-Way Rotating Joint Inspection -----	ES05-34-5011.0R0	0011-0017
8-Way Rotating Joint Inspection -----	ES05-34-5011.1R0	0018-
8-Way Rotating Joint Disassembly And Reassembly -----	ES05-34-6011.0R0	0011-0017
8-Way Rotating Joint Disassembly And Reassembly -----	ES05-34-6011.1R0	0018-
Swing Control Valve Outline And Operation -----	ES05-35-0011.0R0	0011-
4-Series Control Valve Outline And Operation -----	ES05-38-0040.0R0	0011-
Retract Control Valve Outline And Operation -----	ES05-48-0040.0R0	0011-
Check Block Structure And Outline -----	ES05-49-0011.0R0	0011-
Take-Up Cylinder Disassembly And Reassembly -----	ES05-57-6032.0R0	0011-

Section-6 Gantry

Gantry Maintenance Chart -----	ES06-01-2040.0R0	0011-
Gantry Disassembly And Reassembly -----	ES06-01-6040.0R0	0011-
Gantry Bail Maintenance Chart -----	ES06-03-2032.0R0	0011-
Gantry Bail Disassembly And Reassembly -----	ES06-03-6032.0R0	0011-

Section-7 Crane attachment

Sheave Maintenance Chart -----	ES07-09-2040.0R0	0011-
--------------------------------	------------------	-------


Section-13 Electrical System

Electrical Diagram -----	ES13-01-0032.0R0	0011-0028
Electrical Diagram -----	ES13-01-0053.0R0	0029-
Electrical System Standardization -----	ES13-01-9032.0R0	0011-
Storage Battery Servicing And Installation -----	ES13-04-5003.0R0	0011-

Section-14 Tightening Torque Table

General Purpose Tightening Torques -----	ES14-02-0001.0R1	0011-
--	------------------	-------

1 Upper Machinery




ECD0-016S

Solenoid Valve Bank


EB:Emergency Brake

2 Lower Machinery



ECD0-014S


3 Components In Operator's Cab



ECD0-017S

Note: For more details of operating levers, pedals and switches on the panel, refer to the operator's manual.


Power from the engine is separated by the power divider (pump splitter) to drive hydraulic pumps. The rotating energy of engine power is also converted into fluid energy (the flow of high pressure hydraulic oil) which is directed by the control valves, through hydraulic lines, to various actuators.



The hydraulic motor drives the drum via reduction gears. Separatmotors and reduction gears are used for each drum.

1 Structure

The drum shaft mainly consists of a reduction gear case (4), drum shaft (8), clutch (9) and drum (10). The reduction gear (18) and drum shaft (8) are supported through bearings (7),(12) and (13). These are also clamped on the revolving frame with high tensile strength bolts. The clutch assembly is splined to the drum shaft. The drum is designed to rotate freely on the drum shaft with bearings (12). Spur gear lubrication oil is stored in the gear case, being an oil bath type.



ECD1-114S

(1) Hydraulic Motor	(6) Reduction Gear	(11) Bearing Holder	(16) Inspection Cover
(2) Pinion	(7) Bearing	(12) Bearing	(17) Pinion
(3) Level Plug	(8) Drum Shaft	(13) Bearing	(18) Reduction Gear
(4) Reduction Gear Case	(9) Clutch	(14) Filler Cap	
(5) Rotating Joint	(10) Drum	(15) Drain Plug	

Automatic brake and free fall operation

This unit possesses two modes of operation. One is an automatic brake function and the other is a free fall function. The automatic brake function constantly activates the clutch and thus the drum shaft and drum are connected. When the control lever is moved either hoist or lower, the brake is disengaged to rotate the drum. In the case of operation under free fall function, the automatic brake is disengaged at all time, and the control lever moved either to hoist or lower will activate the clutch to connect the drum shaft and drum. Thus the drum is rotated. When the control lever is placed in neutral, the drum becomes free with the clutch disengaged. Therefore, the braking operation by the brake pedal is required. For more details, refer to operator's manual.

2 Inspection And Adjustment

Hydraulic motor Reduction gear case Rotating joint	} Check for oil leakage.
All moving portions	Listen for any unusual noises and smell with load.
Pinion, Gear, Drum	Check for excessive wear, cracks and damage of teeth.
Reduction gear case	Check lubricant oil level. With the level plug removed, the oil should be to the level of the plug hole. If below that level, add oil.
Mounting portions	Check for looseness and missing parts. If loosened or missing, replace and/or retighten with specified torque as required.

Note : After inspecting the above, disassemble or repair, as necessary.

2.1 Oil inspection of reduction gear case

- 1) Remove the level plug (3) and check the oil level. If the level is at the lower part of the level plug (3) hole, the oil is in proper quantity. If the oil level is too low, supply gear oil from the oil filler port.

- When oil overflows from the level plug (3) hole, the oil stands at the standard level.

Note : For proper oils, refer to the operator's manual.

2.2 Oil replacement of reduction gear case


Change oil yearly or 1000 hours of operations, whichever comes first.

- 1) Park the machine on level ground.
- 2) Engage the swing lock and shutdown the engine.
- 3) Wipe off the dirt from the drain plug (15), filler cap (14) and level plug (3) to prevent foreign material from entering.
- 4) Place a clean oil container under the drain plug (15).
- 5) Remove the drain plug (15), filler cap (14) and level plug (3) to drain the oil.

Lubricant capacity :12.2gal. (46lit.)

Note : Check for foreign materials in the drained oil. If foreign materials are found, check the case internal.

- 6) Install the drain plug (15).
- 7) Fill the gear case with lubricant through the filler port to the lower part of the level plug (3) hole.



ECD1-139S


Note : For proper lubricants, refer to the operator's manual.


- 8) Install the level plug (3) and the filler cap (14).

Unit: inches (mm)

Item	Part Name	Number Of Teeth	*1	Allowable Backlash	Treatment
1	Pinion	3	3.083" (78.3)	.083" (2.1)	Replacement
2	Gear	5	5.433" (138.0)		
3	Gear	3	4.307" (109.4)	.102" (2.6)	Replacement
4	Gear	5	7.646" (194.2)		

*1 Allowable Displacement Over A Given Number Of Teeth.






CDD0040Z-E

ECD1-114S

① Hydraulic Motor	⑫ Ball Bearing	⑳ End Plate	㉔ Shaft
② Pinion	⑬ Ball Bearing	㉕ Bolt	㉕ Bearing
③ Plug (With Dipstick)	⑭ Oil Filler Cap	㉖ Spacer	㉖ Spacer
④ Gear Case	⑮ Drain Plug	㉗ Oil Seal	㉗ Oil Check Cap
⑤ Rotating Joint	⑯ Inspection Cover	㉘ Seal Collar	㉘ Cover
⑥ Gear	⑰ Bolt, Washer	㉙ Bolt	㉙ Bolt, Washer
⑦ Roller Bearing	⑱ Reduction Gear	㉚ Spacer	㉚ Bearing
⑧ Drum Shaft	⑲ Bolt	㉛ Bearing Nut, Washer	㉛ Bolt, Washer
⑨ Clutch Assembly	㉑ Snap Ring	㉜ Pinion	㉜ Packing
⑩ Hoist Drum	㉒ Seal Retainer	㉝ Bolt	㉝ Gear Cover
⑪ Bearing Holder	㉓ Hose	㉞ Hose	
		㉟ Drain Cap	

Disassembly

Disassembly Procedure



Work Preparation

Main body support

- 1) Park the machine on level and stable ground.
- 2) Extend the side frame.
For side frame extension, refer to the operator's manual.
- 3) Rest the attachment upon a suitable support.

⚠ WARNING


Since The Component Parts Related To This Procedure Are Heavy, Handle Them Carefully Or Accidents May Result. Use A Hoist To Handle Them Efficiently. Check That The Hoist Capacity Is Sufficient.

⚠ CAUTION

Take The Surroundings Into Consideration, Select A Place Where Safe Operation Is Possible And Take Precautions Against Dangers. Particularly Avoid Slopes.

1 Counterweight Removal

To remove the counterweight with the gantry in the high position, refer to the operator's manual.




Counterweight

ECD2-70S

2 Gantry Folding

- 1) To position the gantry from high to low, refer to the operator's manual.



Gantry

ECB2-34

3 Attachment Removal


- 1) To remove the attachment from the upper section, refer to the operator's manual.

4 Front And Rear Drum Wire Rope Removal

CAUTION

Avoid Injury To Yourself.
Replace Or Rearrange Rope Carefully To
Avoid An Accident. Rope Wrapped Around
Sheaves May Become Twisted.
When Released, The Rope Can Spin As The
Dead End Pins Or Sockets Are Removed.

- 1) Pull out wire ropes from the front and rear drums, and wind them with the winder.



Drum Wedge


Wire Rope

ECD1-120S

CAUTION

Properly Release The Rope During Winding,
Or The Rope May Be Twisted Which Results
In Excessively Deformed Releasing, Causing
Kinks. Kinks Can Shorten Rope Life.

- 2) Remove the drum wedge, and remove the wire rope from the hoist drum.



Winder Types

Proper Wire Rope Releasing

EAM81