

		Serial No.
Section-0 General		
Equipment Layout -----	ES00-03-0034.0R0	1001-
Section-1 Upper Mechanism		
Power Transmission System -----	ES01-01-0034.0R0	1001-
Front And Rear Drum Shaft Structure And Outline -----	ES01-10-0034.0R0	1001-
Front And Rear Drum Shaft Maintenance Chart -----	ES01-10-2034.0R0	1001-
Front And Rear Drum Shaft Disassembly And Reassembly -----	ES01-10-6034.0R0	1001-
Third Drum Shaft Structure And Outline -----	ES01-12-0034.0R0	1001-
Third Drum Shaft Maintenance Chart -----	ES01-12-2034.0R0	1001-
Third Drum Shaft Disassembly And Reassembly -----	ES01-12-6034.0R0	1001-
Boom Hoist Drum Shaft Structure And Outline -----	ES01-15-0034.0R0	1001-
Boom Hoist Drum Shaft Maintenance Chart -----	ES01-15-2034.0R0	1001-
Boom Hoist Drum Shaft Disassembly And Reassembly -----	ES01-15-6034.0R0	1001-
Clutch Structure And Outline (2-Cylinder Type) -----	ES01-17-0034.0R0	1001-
Clutch Maintenance Chart (2-Cylinder Type) -----	ES01-17-2034.0R0	1001-
Clutch Troubleshooting (2-Cylinder Type) -----	ES01-17-4009.0R0	1001-
Clutch Disassembly And Reassembly (2-Cylinder Type) -----	ES01-17-6034.0R0	1001-
Turntable Bearing Maintenance Chart -----	ES01-30-2030.0R1	1001-
Power Divider (Pump Splitter) Disassembly And Reassembly -----	ES01-40-6034.0R0	1001-
Section-2 Lower Mechanism		
Lower General Explanation -----	ES02-01-0034.0R0	1001-
Tread Drive Sprocket Maintenance Chart -----	ES02-05-2034.0R0	1001-
Take-Up Idler Structure And Outline -----	ES02-07-0034.0R0	1001-
Take-Up Idler Maintenance Chart -----	ES02-07-2034.0R0	1001-
Take-Up Idler Disassembly And Reassembly -----	ES02-07-6017.0R0	1001-
Carrier Roller Maintenance Chart -----	ES02-08-2034.0R0	1001-
Track Roller Maintenance Chart -----	ES02-09-2034.0R0	1001-
Track Shoe Maintenance Chart -----	ES02-10-2034.0R0	1001-
Tread Member Maintenance Chart -----	ES02-12-2034.0R0	1001-
Travel Reduction Gear Maintenance Chart -----	ES02-21-2034.0R0	1001-
Travel Reduction Gear And Gear Case Oil Inspection And Replacement -----	ES02-21-5011.0R0	1001-
Section-3 Control System		
Front And Rear Drum Brakes Control Maintenance Chart -----	ES03-05-2034.0R0	1001-
Front And Rear Drum Brakes Control Inspection And Adjustment -----	ES03-05-5034.0R0	1001-
Front And Rear Drum Brakes Control Disassembly And Reassembly -----	ES03-05-6034.0R0	1001-

Section-4 Hydraulic System

Hydraulic Circuit Outline	ES04-01-0034.0R0	1001-1070
Hydraulic Circuit Outline	ES04-01-0034.1R0	1071-
Hydraulic Circuit Pressure Adjustment	ES04-01-5034.0R0	1001-1070
Hydraulic Circuit Pressure Adjustment	ES04-01-5034.1R0	1071-

Section-5 Hydraulic Unit

Variable Delivery Pump Outline And Structure	ES05-02-0011.0R0	1001-
Variable Delivery Pump Troubleshooting	ES05-02-4009.0R0	1001-
Variable Delivery Pump Disassembly And Reassembly	ES05-02-6011.0R0	1001-
Gear Pump Troubleshooting (3-Series Type)	ES05-03-4050.0R0	1001-
Gear Pump Disassembly And Reassembly (3-Series Type)	ES05-03-6034.0R0	1001-
Accumulator Structure And Working	ES05-05-0009.1R0	1001-1070
Accumulator Structure And Working	ES05-05-0009.2R0	1071-
Accumulator Inspection And Adjustment	ES05-05-5009.1R0	1001-
Accumulator Disassembly And Reassembly	ES05-05-6009.2R0	1001-
Rotating Joint Disassembly And Reassembly	ES05-14-6029.0R0	1001-1070
Rotating Joint Disassembly And Reassembly	ES05-14-6029.1R0	1071-
Brake Booster Function And Operation	ES05-16-0011.0R0	1001-
Remote Control Valve Structure And Operation	ES05-17-0009.0R0	1001-1070
Remote Control Valve Structure And Operation	ES05-17-0009.1R0	1071-
Remote Control Valve Troubleshooting	ES05-17-4009.0R0	1001-
Remote Control Valve Disassembly And Reassembly	ES05-17-6009.0R0	1001-1070
Remote Control Valve Disassembly And Reassembly	ES05-17-6009.1R0	1071-
Clutch Cylinder Disassembly And Reassembly (2-Cylinder Type, Right Hand)	ES05-18-6034.0R0	1001-
Automatic Brake Cylinder Disassembly And Reassembly	ES05-19-6032.0R0	1001-
Line Filter Inspection	ES05-30-5011.0R0	1001-
Line Filter Disassembly And Reassembly	ES05-30-6011.0R0	1001-
Return Filter Inspection	ES05-32-5011.0R1	1001-
Return Filter Disassembly And Reassembly	ES05-32-6011.0R0	1001-
8-Way Rotating Joint Inspection	ES05-34-5011.0R0	1001-1070
8-Way Rotating Joint Inspection	ES05-34-5011.1R0	1009-
8-Way Rotating Joint Disassembly And Reassembly	ES05-34-6011.0R0	1001-1070
8-Way Rotating Joint Disassembly And Reassembly	ES05-34-6011.1R0	1009-
Swing Control Valve Outline And Operation	ES05-35-0011.0R0	1001-
2 And 4-Series Control Valve Outline And Operation	ES05-38-0012.1R1	1001-
Check Block Structure And Outline	ES05-49-0011.0R0	1001-
Take-Up Cylinder Disassembly And Reassembly	ES05-57-6034.0R0	1001-

Section-6 Gantry

Gantry Maintenance Chart -----	ES06-01-2034.0R0	1001-
--------------------------------	------------------	-------

Section-7 Crane attachment

Live Mast And Boom Foot Maintenance Chart -----	ES07-08-2034.0R0	1001-
Sheave Maintenance Chart -----	ES07-09-2034.0R0	1001-


Section-13 Electrical System

Electrical Diagram -----	ES13-01-0034.0R0	1001-1070
Electrical Diagram -----	ES13-01-0034.1R0	1071-
Electrical System Standardization -----	ES13-01-9032.0R0	1001-
Storage Battery Servicing And Installation -----	ES13-04-5003.0R0	1001-

Section-14 Tightening Torque Table


General Purpose Tightening Torques -----	ES14-02-0001.0R1	1001-
--	------------------	-------

1 Upper Machinery




ECE0-1S

2 Lower Machinery



ECE0-2S


3 Components In Operator's Cab



ECE0-7S

Note: For more details of operating levers, pedals and switches on the panel, refer to the operator's manual.

Power from the engine is separated by the power divider (pump splitter) to drive hydraulic pumps. The rotating energy of engine power is also converted into fluid energy (the flow of high pressure hydraulic oil) which is directed by the control valves, through hydraulic lines, to various actuators.




ECE1-70S

The hydraulic motor drives the drum via reduction gears. Separate motors and reduction gears are used for each drum.

1 Structure

The drum shaft mainly consists of a reduction gear case ④, drum shaft ⑧, clutch ⑨ and drum ⑩. The reduction gear ⑥ and drum shaft ⑧ are supported through bearings ⑦, ⑫ and ⑬. These are also clamped on the revolving frame with high tensile strength bolts. The clutch assembly is splined to the drum shaft. The drum is designed to rotate freely on the drum shaft with bearings ⑫. Spur gear lubrication oil is stored in the gear case, being an oil bath type.



CED0251Z-E

ECE1-139S

① Hydraulic Motor	⑥ Reduction Gear	⑪ Bearing Holder	⑫ Inspection Cover
② Pinion	⑦ Bearing	⑫ Bearing	
③ Level Plug	⑧ Drum Shaft	⑬ Bearing	
④ Reduction Gear Case	⑨ Clutch	⑭ Filler Cap	
⑤ Rotating Joint	⑩ Drum	⑮ Drain Cap	

Automatic brake and free fall operation

This unit possesses two modes of operation. One is an automatic brake function and the other is a free fall function. The automatic brake function constantly activates the clutch and thus the drum shaft and drum are connected. When the control lever is moved either hoist or lower, the brake is disengaged to rotate the drum. In the case of operation under free fall function, the automatic brake is disengaged at all time, and the control lever moved either to hoist or lower will activate the clutch to connect the drum shaft and drum. Thus the drum is rotated. When the control lever is placed in neutral, the drum becomes free with the clutch disengaged. Therefore, the braking operation by the brake pedal is required. For more details, refer to the operator's manual.

2 Inspection And Adjustment

Hydraulic motor Reduction gear case Rotating joint	Check for oil leakage.
All moving portions	Listen for any unusual noises and smell with load.
Pinion, Gear, Drum	Check for excessive wear, cracks and damage of teeth.
Reduction gear case	Check for lubricant oil level. With the check plug removed, the oil should be to the level of the plug hole. If below that level, add oil.
Mounting portions	Check for looseness and missing parts. If loosened or missing, replace and/or retighten with specified torque as required.

Note: After inspecting the above, disassemble or repair, as necessary.

2.1 Oil inspection of reduction gear case

- 1) Remove the level plug ③ and check the oil level. If the level is at the lower part of the level plug ③ hole, the oil is in proper quantity. If the oil level is too low, supply gear oil from the oil filler port.

- When oil overflows from the level plug ③ hole, the oil stands at the standard level.

Note: For proper oils, refer to the operator's manual.

2.2 Oil replacement of reduction gear case

Change oil yearly or 1000 hours of operations, whichever comes first.


- 1) Park the machine on level ground.
- 2) Engage the swing lock and shutdown the engine.
- 3) Wipe off the dirt from the drain cap ⑮, filler cap ⑭ and level plug ③ to prevent foreign material from entering.
- 4) Place a clean oil container under the drain cap ⑮.
- 5) Remove the drain cap ⑮, filler cap ⑭, level plug ③ and drain the oil.
Lubricant capacity: 6.2gal. (23.4lit.)

Note: Check foreign materials for the drained oil. If many foreign materials are found, check the case internal.


- 6) Screw the drain plug ⑮.
- 7) Fill the gear case with lubricant through the filler port up to the level at the lower part of the level plug ③.

Note: For proper lubricants, refer to the operator's manual.

- 8) Install the level plug ③ and the filler cap ⑭.



ECE1-134S



ECE1-130S