

Massey Ferguson®

1533 / 1540
Compact Tractor

WORKSHOP SERVICE MANUAL 4283359M1

CONTENTS

GENERAL INFORMATION	01
ENGINE WORKSHOP MANUAL	02A
ENGINE	02B
MAJOR COMPONENTS	03
CLUTCH	04
TRANSMISSION	05
HYDROSTATIC TRANSMISSION	06
REAR AXLE AND BRAKES	07
FRONT AXLE	08
HYDRAULICS	09
ELECTRICAL	10
HYDROSTATIC STEERING	11
CAB AND AIR CONDITIONING	12

Massey Ferguson®

1533 / 1540 Compact Tractor

WORKSHOP SERVICE MANUAL 4283359M1

01 - General Information

Contents

GENERAL	
Introduction	01-1
To the Dealers	01-1
Replacement Parts	01-1
Units of Measurement	01-1
Table of Contents	01-1
Page Numbers	01-1
Tractor Identification	01-2
Model/Serial Numbers	01-2
SPECIFICATIONS AND CAPACITIES	
General Dimensions	01-5
General Dimensions	01-5
Engine Oil	01-7
Engine Coolant	01-7
Fuel Tank	01-7
Transmission & Differential Housing (Including Hydraulic System)	01-7
Front Axle (4 WD)	01-7
Grease Fittings	01-7
Engine	01-8
Transmission	01-9
Hydrostatic	01-9
Power Take Off (PTO)	01-9
Hydraulics	01-10
Electrical System	01-10
Capacities	01-10
Maximum Axle Loading	01-10
Lubrication / Fill Points	01-11
Periodic Inspection and Maintenance Chart	01-12
PRECAUTIONS FOR DISASSEMBLY	
General Precautions For Disassembly And Installation	01-15
Before Operation	01-15
Precautions To Be Followed When Installing Standardized Parts	01-15
STANDARD TORQUE CHART	
Standard Torque Chart	01-19
CONVERSION TABLE	
Conversion Tables	01-3
INDEX	01-5

GENERAL

INTRODUCTION

This service manual has been prepared with the latest service information available at the time of publication. Read the service manual carefully before doing any service on the machine. This manual is one of the most important tools available to the service technician.

Right-hand and left-hand, as used in this manual, is determined by facing the direction the machine will travel when in use.

The photos, illustrations, and data used in this manual were current at the time of printing, but due to possible production changes, your machine can vary slightly. The Manufacturer reserves the right to redesign and change the machine as necessary without notification.



WARNING: Some pictures in this manual show the machine with shields or guards removed to allow for a better view of the subject of the picture. All shields and guards must be in position before operating the machine.

TO THE DEALERS

This manual was developed to provide the best possible information, technical support and service to the customer. Review the Table of Contents and basic layout to become familiar with locations of pertinent information such as maintenance table, specifications and etc.

REPLACEMENT PARTS

To receive efficient service, always remember to give the dealer the following information:

- Correct part description or part number.
- Model number of your machine.
- Serial number of your machine.

UNITS OF MEASUREMENT

Measurements are given in metric units followed by the equivalent in US units. Hardware sizes are given in millimeters for metric hardware and inches for U.S. hardware.

TABLE OF CONTENTS

A Table of Contents is in the front of this manual. The Table of Contents shows the divisions. The individual divisions also have a Table of Contents.

PAGE NUMBERS

All page numbers are made of two numbers separated by a dash, such as 01-25. The number before the dash is the division number. The number following the dash is the page number in that division. Page numbers will be at the lower right or left of each page.

General

TRACTOR IDENTIFICATION

Model/Serial Numbers

FIG. 1: Chassis number (1) is stamped in right side of front frame.




FIG. 1

FIG. 2: Engine model number (1) is cast on right side of engine block, below the injection pump.

Engine serial number (2) is stamped into cylinder block, below engine model number.

Engine Serial Number




FIG. 2

FIG. 3: The tractor identification plate (1) is located below the operator's seat.




FIG. 3

FIGS. 4–6: The identification plate contains model number and tractor serial number.



FIG. 4




FIG. 5



FIG. 6

NOTES

SPECIFICATIONS AND CAPACITIES

GENERAL DIMENSIONS




FIG. 7

FIG. 7: Non Cab Tractor Dimensions.

General Dimensions

Overall Height (1)	2209 mm (87 in)
Overall Length (2)	3070 mm (121 in)
Minimum Width (3)	
(Ag Tires)	1680 mm (66.1 in)
(Turf Tires)	1549 mm (61 in)
Wheelbase (4)	
33 Horsepower	1770 mm (70 in)
40 Horsepower	1770 mm (70 in)
Ground Clearance (Ag Tires)	360 mm (14 in)
Front Wheel Tread	
2WD	1120 mm (44.1 in)
33 Horsepower 4WD	1130 to 1271 mm (44 to 50 in)
40 Horsepower 4WD	1130 to 1271 mm (44 to 50 in)
Turning Radius	
With Brake	2500 mm (98 in)
Without Brake	3100 mm (122 in)
Weight	
33 Horsepower (4wd)	1375 kg (3031 lb)
40 Horsepower (4wd)	1390 kg (3058 lb)

Specifications And Capacities




FIG. 8

FIG. 8: Cab Tractor General Dimensions.

Overall Height (1) (Ag Tires).....	2220 mm (87.4 in)
Overall Length (2)	3070 mm (121 in)
Minimum Width (3)	
Ag Tires	1565 mm (62 in)
Turf Tires	1530 mm (60 in)
Wheelbase (4)	
33 Horsepower	1770 mm (70 in)
40 Horsepower	1930 mm (76 in)
Ground Clearance (Ag Tires)	360 mm (14 in)
Weight	
33 Horsepower	1535 kg (3384 lb)
40 Horsepower	1823 kg (4023 lb)
Front Wheel Tread	1130 to 1271 mm (44 to 50 in)
Rear Wheel Tread.....	1190 to 1495 mm (47 to 59 in)
Turning Radius With Brake.....	2500 mm (98 in)

Engine Oil

Use the appropriate SAE viscosity. Oil must meet or exceed MIL-L-46152 requirements, API Service CC.

Capacity (Crankcase and Filter).....	4.7 liters (5.0 US qt)
25 degrees C (78 degrees F)	SAE 30W, 10W-30
Below 0 degrees C (32 degrees F)	SAE 20W, 10W-30
0 to 25 degrees C (32 to 78 degrees F).....	SAE 20W, 10W-30
15W-40 may be used in ambient temperatures above -10 degrees C (14 degrees F).	
Initial Oil and Filter Change	50 hours
Oil and Filter Change, Thereafter.....	Every 100 hours

Engine Coolant

Freezing Protection (Original Factory Fill).....	-34 degrees C (-30 degrees F)
Recommended Coolant	50/50 mixture ethylene glycol and water
System Capacity.....	7.6 liters (8.0 US qt)

Fuel Tank

Capacity	50.0 liters (13.2 US gals)
Fuel Recommended, Above 4° C (39° F)	No. 2 or No. 2-D
Fuel Recommended, Below 4° C (39° F)	No. 1 or No. 1-D

Transmission & Differential Housing (Including Hydraulic System)

Capacity	31 liters (8.2 US gals)
Recommended Lubricant.....	Permatran III or 821XL
Recommended Change Interval.....	First 50 hours, every 300 hours thereafter

Front Axle (4 WD)

Capacity (Common Reservoir).....	7.5 liters (1.9 US gals)
Recommended Lubricant.....	Permatran III or 821XL
Recommended Change Interval.....	First 50 hours, every 300 hours thereafter

Grease Fittings

Grease Interval (All Fittings).....	Every 50 hours
Recommended Grease	Lithium multi-purpose grease EP2

NOTE: Change intervals stated above are for normal usage. Due to adverse operating conditions, that may be experienced (extremely dusty or muddy), change intervals may need to be more frequent.