



PARTS MANUAL

5465H COMBINE

PRINTED BY :
heavy-equipmentmanual.com

5465H

Cutting table trailer

GENERAL


TRAILER BAR 2003.....	5F.00.0
TRAILER 2003.....	5F.00.1
TRAILER LIGHT ARM.....	5F.00.2
TRAILER LIGHT ARM GERMANY ONLY.....	5F.00.3

TRAILER BAR 2003

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[5465H]

1	0424422	1	crank
2	0633637	1	shock absorber
3	7400032	4	washer
4	7412469	4	washer
5	6220867	4	screw
6	6593438	2	nut
7	0493699	1	arm
8	R701116	1	arm
9	6252787	2	screw
10	6234397	4	screw
11	7400034	8	washer
12	R701114	1	plate
13	6594238	4	nut
14	8033689	2	spacer PG11
15	R701113	1	square pulley
16	R699534	1	plate




TRAILER 2003

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5465H]




22-11-04

1	R698921	2	arm
2	R698920	2	stopper
3	7400032	16	washer
4	6594038	8	nut
5	6221467	8	screw
6	6594048	4	nut
7	R701111	2	pin
8	6226167	4	screw
9	R698945	2	support
10	R701137	2	pin
11	7414473	1	washer
12	6506631	1	nut
13	R701110	1	pin
14	6231567	6	screw
15	7400034	4	washer
16	R698943	2	plate
17	6594238	14	nut
18	6231977	2	screw
19	R659414	2	special bushing
20	7812410	2	pin
21	8020230	12	reflector
22	R601344	2	pin
23	0633897	2	rubber
24	R701149	1	support sx/lh/li
25	R701345	1	latch dx/rh/re
26	8020231	2	reflector
27	8020232	2	reflector
28	R701150	1	support sx/lh/li
29	R701344	1	latch dx/rh/re
30	R701133	1	pin
31	7814285	4	pin
32	6231767	4	screw
33	6221260	4	screw
34	0480571	2	tube
			->
36	6593438	1	nut
37	7400040	1	spring washer
38	0480581	2	tyre
			->
38	0492963	2	ring
			->

TRAILER 2003

Fig.	P/n	QTY	Name
39	0480570	2	rim
			->
39	0498951	2	rim
			->
40	6594438	10	nut
41	7400036	10	washer
42	R638582	2	cover
43	0562006	2	lock-nut
44	0563006	2	nut
45	0562027	2	spring washer
46	0252420	2	grease gun
47	0480566	2	bearing
48	R695038	2	hub
49	0480567	2	bearing
50	R695040	2	guard




22-11-04

TRAILER LIGHT ARM

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[5465H]

1	8070022	2	side lamp
2	8020240	2	reflector
3	R701127	1	arm
4	0415225	1	spring
5	7414059	1	washer
6	6229867	1	screw
7	8020260	1	triangle
8	7400030	8	washer
9	6210667	8	screw
10	8020230	2	reflector
11	R701125	1	arm
12	8014630	1	cable
13	8055562	2	pipe fitting
14	8035095	2	headlight
15	8035093	2	headlight
16	6594238	1	nut
17	7400034	2	washer
18	6232973	1	screw




TRAILER LIGHT ARM GERMANY ONLY

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[5465H]

1	8070021	2	side lamp
2	8020240	2	reflector
3	R701127	1	arm
4	0415225	1	spring
5	7414059	1	washer
6	6229867	1	screw
7	0813693	1	plate
8	7400030	8	washer
9	6210667	8	screw
10	8020230	2	reflector
11	R701125	1	arm
12	8014630	1	cable
13	8055562	2	pipe fitting
14	8035095	2	headlight
15	8035093	2	headlight
16	6594238	1	nut
17	7400034	2	washer
18	6232973	1	screw



5465H

Loss monitor


GENERAL

THRESHING MONITOR LH-500.....	5E.00.0
THRESHING MONITOR LH-500 MED./MAX.....	5E.00.1
DHC.....	5E.00.2

THRESHING MONITOR LH-500

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[5465H]



1	R701817	1	support
2	R702121	1	index
2	R702122		index
3	R701745	2	shaker coating
4	R692442	2	plate
5	8033743	4	level indicator
6	R700991	2	plate
7	R701691	1	cap
8	8033744	1	level indicator
9	8033723	1	screw
10	8033722	1	magnet
11	8033721	1	spring washer
12	R699833	1	support
13	9701040	1	cable
14	9701171	1	cable
15	R699744	2	rail

5465H

Section: Loss monitor


Ref: 5E.00.1

THRESHING MONITOR LH-500 MED./MAX.

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5465H]



4-11-04

1	R701817	1	support
2	R702123	1	index
			B
2	R702124	1	index
			C
2	R702125	1	index
			A&B
2	R702126	1	index
			A&C
3	R692442	2	plate
4	R701745	2	shaker coating
5	8033743	4	level indicator
6	R701691	1	cap
7	R700991	2	plate
8	9701174	1	cable
9	9701809	1	cable
10	0814719	1	tube
11	8094952	1	switch
12	9701176	1	cable
13	R693275	2	ring
14	R701813	1	support
15	9701172	1	cable
16	R699744	2	rail
17	R693266	1	support
18	8033740	1	level indicator
			A
19	R701861	1	ring
20	R699814	4	plate
			-> 555469
20	R703129	1	support
			-> 555470
21	R700667	1	connecting plate
			A
22	R699547	1	clamp
			A
23	8033742	6	level indicator
24	8033723	7	screw
25	8033722	7	magnet
26	8033721	7	spring washer
27	8063236	2	switch
28	9701170	1	cable