



PARTS MANUAL

5485HT CLIMBER COMBINE

PRINTED BY :
heavy-equipmentmanual.com

5485HT CLIMBER

Belts

GENERAL

BELTS AND CHAINS TS HD.....	5B.00.0
-----------------------------	---------

5485HT CLIMBER

Section: Belts


Ref: 5B.00.0

BELTS AND CHAINS TS HD

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5485HT CLIMBER]



1	0657101	1	chain
2	0614225	1	belt
3	0615109	1	belt
4	0615184	1	belt
5	0615182	1	belt
6	0619090	1	MD
7	0615135	1	compound belt
8	0613122	2	belt
9	0615147	1	belt
10	0615151	1	belt
11	0615168	1	belt
12	0614215	1	belt
13	0619080	2	compound belt
14	0614242	1	belt
15	0614222	1	belt
16	0614212	1	belt
17	A	1	support 44ET 130
18	0613104	1	belt
19	0615139	1	belt
20	0657110	1	chain
21	0619192	1	belt
22	0614227	2	v-belt set
23	0619062	1	belt
24	0614150	1	belt
25	0619169	1	belt
26	0619041	1	belt
27	0619085	1	belt
28	0615190	1	belt
29	0619191	1	belt

5485HT CLIMBER

Cab and control units

GENERAL

OPERATOR'S PLATFORM CLIMBER.....	54.00.0
STEERING WHEEL DL.....	54.00.1
SEAT KAB.....	54.00.2
CABINE STAIRS.....	54.00.3
SEAT, 2ND DRIVER.....	54.00.4
CABIN DL.....	54.00.5
INSTRUMENT PANEL DL.....	54.00.6
LIGHT ARMS DL.....	54.00.7
DRIVE LEVER, HYDRAULIC DL.....	54.00.8
CAB PANES AND NOISE INSULATION DL.....	54.00.9
FAN AND AIR HEATER.....	54.00.10

5485HT CLIMBER

Section: Cab and control units


Ref: 54.00.0

OPERATOR'S PLATFORM CLIMBER

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5485HT CLIMBER]




2	6226367	30	screw
3	6226567	8	screw
4	6243390	4	screw
5	6594148	30	nut
6	6594438	4	nut
7	7400033	8	washer
8	7400036	2	washer
9	7414225	8	washer
10	0633873	4	flange
11	0633871	4	silent-block
12	0633874	4	cams
13	R695831	1	support
16	R699931	1	support
17	R699932	1	support
18	R699940	1	support
19	R695127	1	base
20	R699907	1	support sx/lh/li
21	R699908	1	support dx/rh/re
23	0492841	1	joint
24	0633567	1	insulator
25	0839205	1	knob
26	6210667	3	screw
27	6506031	1	nut
28	6593838	4	nut
29	7400030	1	washer
30	R697201	1	bracket
31	R698844	1	stay
32	R698845	1	support
33	R681035	1	plate

5485HT CLIMBER

Section: Cab and control units

Ref: 54.00.1

STEERING WHEEL DL



Notes:

[5485HT CLIMBER]

Fig.	P/n	QTY	Name
1	0480341	1	steering wheel
2	0480342	1	switch
3	0480348	1	steering shaft
4	0480343	1	adjusting frame
5	0480349	1	guard sx/lh/li
6	0480345	1	guard dx/rh/re
7	0480347	1	spring
8	0480346	1	box
9	0480344	1	pedal
10	6594148	1	nut

5485HT CLIMBER

Section: Cab and control units


Ref: 54.00.2

SEAT KAB

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[5485HT CLIMBER]

1	0492420	1	seat
2	0480644	1	support
3	0480643	1	support



5485HT CLIMBER

Section: Cab and control units


Ref: 54.00.3

CABINE STAIRS

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5485HT CLIMBER]



6	200.10.101	1	piston pin
7	16.6592	1	flat washer
8	5.30.1336	1	split pin
17	200.10.108	1	division
18	151.008.2	1	self-locking nut
18	8.25.5739.2	1	screw
18	8.6592	1	flat washer
19	200.10.105	1	rod
21	20.6592	1	flat washer
22	20.15.5593.2	1	nut
23	4.40.1336	1	split pin
25	200.10.076	2	threaded joint
26	6.30.1481	4	roll pin
27	200.10.102	1	foot board
28	200.10.126	4	small plate
29	200.10.127	2	right hand side panel
30	200.10.109	1	foot board
31	151.008.2	8	self-locking nut
31	239.393.1	8	disc Ø 8
31	8.30.5739.2	8	screw
32	200.10.104	1	climbing steps
33	24.110.5739.2	1	screw
35	185.20.557	1	mandrel
24	200.10.107	1	joint

5485HT CLIMBER

Section: Cab and control units

Ref: 54.00.4


SEAT, 2ND DRIVER

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5485HT CLIMBER]

2	7266502	6	block
11	0492409	1	seat
13	7268907	3	block
14	7414055	3	washer
15	R689943	1	cover



5485HT CLIMBER

Section: Cab and control units


Ref: 54.00.5

CABIN DL

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5485HT CLIMBER]



1	8080026	4	headlight
2	R699304	2	rail
3	0633875	2	insulator
4	R697391	1	support dx/rh/re
5	R699310	1	plate dx/rh/re
6	R699017	1	rail
7	R699015	1	rail
8	R699050	1	clamp
9	R699101	1	pin
10	R699024	1	support
11	R700430	1	connecting plate
12	R699325	2	plate
13	R699021	2	support
14	R699614	2	plate
15	R697389	1	support sx/lh/li
17	R699007	1	support
18	0633889	1	plate
19	0493727	1	valve
20	R699023	1	clamp
21	R699027	1	plate
22	0492348	1	air filter
23	R698719	1	filter
24	R698716	1	cover
25	0871053	2	knob
26	R699014	1	rail
27	R699016	1	rail
28	R698369	1	plate
29	R699902	1	cab
30	0839201	2	connector
31	6220867	2	screw
32	7400032	2	washer
33	R699020	1	support
34	6548514	1	nut
37	R699044	1	support
38	R698337	1	guard dx/rh/re
39	R699331	1	rail
40	R698338	1	door
41	R698336	1	guard sx/lh/li
42	6028081	28	screw
43	7268107	5	plate
44	7414384	5	spring washer