



PARTS MANUAL

5585HT COMBINE

PRINTED BY :
heavy-equipmentmanual.com

5585HT

Belts

GENERAL

BELTS LH.....	5B.00.0
BELTS RH.....	5B.00.1
BELTS TS RH.....	5B.00.2
BELTS TS LH.....	5B.00.3

5585HT

Ref: 5B.00.0

Section: Belts



BELTS LH

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5585HT]

1	0615165	2	v-belt set
2	0615164	2	belt
3	0619090	1	compound belt
4	0619082	1	belt
5	0619091	1	belt
6	0619092	1	belt
7	0619093	1	belt
			STD
7	0619096	1	belt
			EXTENDED
8	0615161	1	belt
9	0615162	1	belt
10	0615163	1	belt
11	0615167	1	belt
12	0615169	1	belt



Section: Belts




BELTS RH

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5585HT]

1	0614217	1	belt
2	0614242	1	belt
3	0613104	1	belt
4	0657116	1	chain
5	0615139	1	belt
6	0657110	1	chain
7	0619169	1	belt
			400-1150 RPM
7	0619179	1	belt
			600-1300 RPM
8	0619071	1	belt
9	0619181	1	belt



Section: Belts


BELTS TS RH

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5585HT]

1	0614217	1	belt
2	0614242	1	belt
3	0613104	1	belt
4	0657116	1	chain
5	0615139	1	belt
6	0657110	1	chain
7	0619190	1	belt
			600-1300 RPM
7	0619191	1	belt
			400-1150 RPM
8	0619071	1	belt
9	0619181	1	belt
10	0619077	1	compound belt
			TS




Section: Belts

BELTS TS LH


Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5585HT]



1	0615165	2	v-belt set
2	0615142	2	v-belt set
3	0619095	1	belt
4	0619082	1	belt
5	0619091	1	belt
6	0619092	1	belt
7	0619093	1	belt
			STD
7	0619096	1	belt
			EXTENDED
8	0615161	1	belt
9	0615162	1	belt
10	0615163	1	belt
11	0615167	1	belt
12	0615169	1	belt



5585HT

Cab and control units

GENERAL


CABINE HOLDERS STD.....	54.00.0
CABINE HOLDERS DL.....	54.00.1
GEAR LEVER, CIT.....	54.00.2
CABIN STD.....	54.00.3
CABIN DL.....	54.00.4
CAB PANES AND NOISE INSUL. STD.....	54.00.5
CAB PANES AND NOISE INSUL. DL.....	54.00.6
CABINE STAIRS.....	54.00.7
CABINE STAIRS 2003.....	54.00.8
STAIRS, Laterally Turnable DL.....	54.00.9
LIGHT ARMS STD.....	54.00.10
DOORS, LIGHT ARMS, DL.....	54.00.11
INSTRUMENT PANEL STD.....	54.00.12
INSTRUMENT PANEL DL.....	54.00.13
CONTROL LEVER AND -CABLE.....	54.00.14
STEERING WHEEL 3-ADJUST.....	54.00.15
SEATS.....	54.00.16
SEATS.....	54.00.17
FAN AND AIR HEATER.....	54.00.18
AIR CONDITIONING TS.....	54.00.19
CLIMATE CONTROL SYSTEM.....	54.00.20

CABINE HOLDERS STD

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5585HT]




1	R685326	1	flange
2	R696964	1	support dx/rh/re
3	R697377	1	support
4	R696963	1	support sx/lh/li
5	R696987	1	support
6	R696986	1	support
7	R696990	1	crosspiece
8	R696996	1	support
9	6220867	6	screw
10	R699333	1	plate
11	R698844	1	stay
12	R699332	1	cover
13	R697201	1	bracket
14	R699138	1	ring for fitting sx/lh/li
21	R698051	4	shock absorber
22	6221267	12	screw
23	7400032	12	washer
24	6594038	12	nut
25	6243390	4	screw
26	6226567	16	screw
27	6594148	16	nut
28	6594438	4	nut
29	6231560	6	screw
31	6594238	6	nut
32	6226367	6	screw
33	6210667	2	screw
34	7400033	13	washer
35	6226367	7	screw
36	7268907	4	block
40	6593838	2	nut

CABINE HOLDERS DL

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[5585HT]



1	R699133	1	plate
2	R699034	1	support dx/rh/re
3	R697377	1	support
4	R699033	1	support sx/lh/li
5	R696987	1	support
6	R696986	1	support
7	R696990	1	crosspiece
8	R699035	1	support
9	R699131	1	support
10	R699111	1	plate
11	0633888	2	frame
12	R699143	1	rail
13	R699139	1	ring for fitting dx/rh/re
14	R699138	1	ring for fitting sx/lh/li
15	7400030	2	washer
16	0450491	1	tank
17	8095753	1	valve
18	R699335	1	tube
19	R697201	1	bracket
20	R698844	1	stay
21	R698051	4	shock absorber
22	6221267	12	screw
23	7400032	12	washer
24	6594038	12	nut
25	6243390	4	screw
26	6226567	16	screw
27	6594148	16	nut
28	6594438	4	nut
29	6231560	6	screw
30	7400034	2	washer
31	6594238	8	nut
32	6226367	6	screw
33	6210667	2	screw
34	7400033	13	washer
35	6226367	7	screw
36	7268907	4	block
37	7268107	4	plate
38	7414384	4	spring washer
39	6211467	1	screw
40	6593838	2	nut
41	R699102	1	support

5585HT

Section: Cab and control units

Ref: 54.00.1

CABINE HOLDERS DL

Fig.	P/n	QTY	Name
41	R701652	1	-> 660093 support -> 660094

