



PARTS MANUAL

AGROMAXX 60 LD TRACTOR

PRINTED BY :
heavy-equipmentmanual.com

AGROMAXX 60 LD

B0 - ENGINE

CYLINDER BLOCK

CRANKCASE.....	B0.01.0 (2)
MONOBLOC ENGINE-GEARBOX CONNECTING FLANGE.....	B0.01.4 (1)

CRANKSHAFT

CRANKSHAFT.....	B0.02.0 (1)
CRANKSHAFT.....	B0.02.0 (2)
CRANKSHAFT PULLEY.....	B0.02.3 (1)
ENGINE FLYWHEEL.....	B0.02.5 (1)
ENGINE FLYWHEEL.....	B0.02.8 (1)
COOLANT PUMP DRIVEBELT.....	B0.02.9 (1)

CYLINDERS - PISTONS - CONNECTING RODS

CYLINDER - PISTON - CONNECTING ROD.....	B0.03.0 (1)
---	-------------

TIMING

CAMSHAFT.....	B0.04.0 (2)
TIMING CASE.....	B0.04.4 (1)

CYLINDER HEAD

CYLINDER HEAD.....	B0.05.0 (1)
--------------------	-------------

LUBRICATION

ENGINE OIL PUMP.....	B0.06.0 (1)
LUBRICATION.....	B0.06.3 (1)
SEDIMENTER BOWL BREATHER PIPE.....	B0.06.6 (1)
FUEL SETTLING FILTER VENT HOSE BRACKET.....	B0.06.7 (1)
PIPE FOR OIL PRESSURE SENSOR.....	B0.06.11 (1)
LUBRICATION.....	B0.06.12 (1)
LUBRICANT OIL SUCTION PIPE.....	B0.06.14 (1)
ENGINE OIL PAN.....	B0.06.17 (1)
ENGINE OIL FILTER.....	B0.06.20 (1)

FUEL INJECTION SYSTEM

INJECTION PUMP DRIVE.....	B0.07.0 (1)
INJECTION PUMP - INJECTOR.....	B0.07.10 (1)
INJECTION PUMP PARTS - 555 - BOSCH.....	2.4619.030.0/30.A
INJECTOR NOZZLE HOLDER COMPONENTS.....	2.4719.190.0.A

MECHANICAL - ELECTRONIC GOVERNOR

MECHANICAL ENGINE GOVERNOR.....	B0.08.0 (1)
GOVERNOR PARTS.....	0.014.8125.4.A
GOVERNOR PARTS.....	0.014.8125.4.B
GOVERNOR PARTS.....	0.014.8125.4.C

COOLING

CYLINDER HEAD WATER OUTLET MANIFOLD.....	B0.09.0 (1)
COOLING WATER PUMP - V-GROOVED PULLEY.....	B0.09.7 (1)
COOLING WATER PUMP.....	0.014.3346.4.A

INTAKE - EXHAUST MANIFOLDS


AIR INTAKE MANIFOLD - EXHAUST MANIFOLD..... B0.10.2 (1)

CRANKCASE

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROMAXX 60 LD 2WD] [AGROMAXX 60 LD 4WD]



2	2.1532.072.0	1	oil seal 26.70x1.78
3	2.3199.405.2	1	plug m 28 p.1.5
5	2.0432.003.7	11	stud bolt m 8 p.1.25 / p.1 x 20
6	2.1559.188.2	3	bush 11.4 x 14 x16
7	2.1539.259.0	6	special oil seal 107.62x2.62
8	2.1560.010.0	1	gasket 14.2 x 20
9	2.3199.292.0	1	plug 1/4" gas
10	0.014.8700.4	1	crankcase
10.1	2.3130.001.1	9	plug 1/8" gas
10.2	2.3130.002.1	2	plug 1/4" gas
10.3	2.3130.003.1	2	plug 3/8" gas
10.4.1.2.1.1	0.065.1112.7/10	1	support
10.4.1.2.2	2.1699.165.0	1	bush 12.3x15x16
10.4.1.3	0.065.1114.0/10	2	support
10.4.1.4	0.065.1116.3	1	support
10.4.1.4.2	2.1699.165.0	1	bush 12.3x15x16
10.4.1.5	0.065.1117.0	8	screw m 12 x 100
10.4.2	0.065.1140.0	3	special bushing 59X55X20
10.4.3	0.065.1141.0	1	special bushing 59X55X30
10.4.4	0.014.1340.0	1	pin
10.5	2.3179.012.0	1	plug 60
11	0.066.1152.0/10	4	gasket
14	2.1549.154.2	3	bush 4.8x5.8x16
28	2.3131.004.2	1	plug m 18 p.1.5

AGROMAXX 60 LD

Section: B0 - ENGINE

Ref: B0.01.4 (1)


MONOBLOC ENGINE-GEARBOX CONNECTING FLANGE

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROMAXX 60 LD 2WD] [AGROMAXX 60 LD 4WD]

1	0.015.8814.0	1	flange
2	2.0112.511.2	8	screw m 14 p.2 x 30
3	2.0432.255.7	2	stud bolt m 12 p.1.75-1.25x25
4	2.1651.912.0	4	cylindrical plug 12x28
5	2.0512.404.7	2	screw




19_38511_01_0-A-001

CRANKSHAFT

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[AGROMAXX 60 LD 2WD] 12937 <- [AGROMAXX 60 LD 4WD] 12937 <-

7.1	0.007.1554.0/20	1	crankshaft
8	0.065.1215.0/10	4	main half bushing STANDARD
9	0.065.1216.0/10	4	main half bushing STANDARD
10	0.065.1218.0	4	shim STANDARD
15	0.065.1254.0/20	1	gasket
16	0.007.1711.0/10	1	cover
17	2.1475.002.2	9	conical washer 8
18	2.0112.207.2	9	screw m 8 p 1.25 x 20
19	2.1529.073.0	1	special oil seal 110x130x13
22	2.1599.524.7	1	washer 21x60x12
23	0.065.1323.0/30	1	gear Z = 29
24	2.1651.915.0	1	pin 12x35
25	2.3130.001.1	3	plug 1/8" gas
26	2.1720.006.0	1	key 4x6.5
801	0.065.1215.7	1	main half bushing - mm 0.25
802	0.065.1215.8	1	main half bushing - mm 0.50
901	0.065.1216.7	1	main half bushing - mm 0.25
902	0.065.1216.8	1	main half bushing - mm 0.50
1001	0.065.1218.7	1	shim + mm 0.10
1002	0.065.1218.8	1	shim + mm 0.15



19_N8112_00_0-A-001

AGROMAXX 60 LD

Section: B0 - ENGINE

Ref: B0.02.0 (2)


CRANKSHAFT

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROMAXX 60 LD 2WD] -> 13530 [AGROMAXX 60 LD 4WD] -> 13530

7	0.019.2255.0/20	1	crankshaft
8	0.019.5455.0	4	main half bushing STANDARD
9	0.019.5456.0	4	main half bushing STANDARD
10	0.065.1218.0	4	shim STANDARD
15	0.065.1254.0/20	1	gasket
16	0.007.1711.0/10	1	cover
17	2.1475.002.2	9	conical washer 8
18	2.0112.207.2	9	screw m 8 p 1.25 x 20
19	2.1529.073.0	1	special oil seal 110x130x13
22	2.1599.524.7	1	washer 21x60x12
23	0.065.1323.0/30	1	gear Z = 29
24	2.1651.915.0	1	pin 12x35
26	2.1720.006.0	1	key 4x6.5
1001	0.065.1218.7	1	shim + mm 0.10
1002	0.065.1218.8	1	shim + mm 0.15



19_N8112_00_0-A-002


CRANKSHAFT PULLEY

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROMAXX 60 LD 2WD] [AGROMAXX 60 LD 4WD]

3	0.014.5093.0	1	pulley
5	0.085.1248.0/20	1	hub
6	2.0399.144.7/10	1	screw m 20 p.1.5x51
8	2.1720.006.0	1	key 4x6.5



I9_38512_04_0-A-001


ENGINE FLYWHEEL

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROMAXX 60 LD 2WD]

1	0.012.0925.3	1	flywheel
1.2	0.069.1242.0	1	crown wheel Z = 121
2	2.0119.174.0/10	6	screw m 12 p.1.25x45
3	2.2041.008.9	1	ball bearing 20x47x14



I9_38512_02_0-A-001

AGROMAXX 60 LD

Section: B0 - ENGINE

Ref: B0.02.8 (1)

ENGINE FLYWHEEL

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROMAXX 60 LD 2WD] [AGROMAXX 60 LD 4WD]

1	0.007.1617.3/30	1	flywheel
1.2	0.069.1242.0	1	crown wheel Z = 121
2	2.0119.174.0/10	6	screw m 12 p.1.25x45
3	2.2041.008.9	1	ball bearing 20x47x14

