



PARTS MANUAL

AGROTRON L720

TRACTOR

PRINTED BY :

heavy-equipmentmanual.com

AGROTRON L720

A0 - TRACTOR

CONSUMABLE MATERIALS

LUBRICANTS AND SEALANTS.....A0.03.0 (1)

AGROTRON L720

Section: A0 - TRACTOR

Ref: A0.03.0 (1)


LUBRICANTS AND SEALANTS

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROTRON L720]

153 01016121 1 adhesive

**9_73771_10_0-D-001**

AGROTRON L720

B0 - ENGINE

GENERAL

ENGINE..... B0.00.0 (1)

CYLINDER BLOCK

FASTENINGS..... B0.01.0

SERIE GUARNIZIONI..... B0.01.2

CRANKCASE BREATHER..... B0.01.3

CRANKCASE BREATHER..... B0.01.4

BLEEDING TUBE..... B0.01.5

CRANKCASE..... B0.01.6

ACCESSORIES..... B0.01.7

OIL FILLER NECK..... B0.01.8

ACCESSORIES..... B0.01.9

FRONT COVER..... B0.01.10

PLUG..... B0.01.11

FRONT COVER..... B0.01.12

CLOSING COMPONENTS..... B0.01.14

ACCESSORIES..... B0.01.16

FILLER CAP..... B0.01.18

OIL PRESSUR.SWITCH..... B0.01.19

PISTON COOL.NOZZLE..... B0.01.20

CLOSING COMPONENTS..... B0.01.22

OIL RETURN..... B0.01.23

OIL RETURN..... B0.01.24

CRANKSHAFT

FASTENINGS..... B0.02.0

VIBRATION DAMPER..... B0.02.1

PLUG..... B0.02.2

CRANKSHAFT..... B0.02.3

ACCESSORIES..... B0.02.4

CRANKSHAFT..... B0.02.5

FLYWHEEL..... B0.02.6

CYLINDERS - PISTONS - CONNECTING RODS

PISTON..... B0.03.0

PISTON..... B0.03.1

CONNECTING ROD..... B0.03.2

TIMING

FASTENINGS..... B0.04.0

FASTENINGS..... B0.04.1

FASTENINGS..... B0.04.3

BUSH..... B0.04.4

ROCKER ARM BRACKET..... B0.04.5

ROCKER ARM BRACKET.....	B0.04.6
ROCKER ARM BRACKET.....	B0.04.8
ROCKER ARM BRACKET.....	B0.04.9
ROCKER ARM BRACKET.....	B0.04.10
ROCKER ARM BRACKET.....	B0.04.11
ROCKER ARM BRACKET.....	B0.04.12
CAMSHAFT.....	B0.04.13
CAMSHAFT.....	B0.04.14
VALVE DRIVE.....	B0.04.15
GEARCASE.....	B0.04.16
GEARCASE.....	B0.04.17
CYLINDER HEAD	
FASTENINGS.....	B0.05.0
SEALING.....	B0.05.1
ENGINE MOUNTING.....	B0.05.2
CLOSING COMPONENTS.....	B0.05.4
CLOSING COMPONENTS.....	B0.05.5
CYLINDER HEAD.....	B0.05.6
CYLINDER HEAD.....	B0.05.7
ROCKER ARMS COVER.....	B0.05.8
VALVE MECHAN.COVER.....	B0.05.9
ROCKER ARMS COVER.....	B0.05.10
LUBRICATION	
ADAPTER.....	B0.06.0
SEALING.....	B0.06.1
BLANKING PARTS.....	B0.06.2
OIL SUCTION PIPE.....	B0.06.3
CLOSING COMPONENTS.....	B0.06.4
OIL PAN.....	B0.06.5
OIL COOLER BOX.....	B0.06.6
CLOSING COMPONENTS.....	B0.06.8
CLOSING COMPONENTS.....	B0.06.10
OIL COOLER BOX.....	B0.06.11
OIL COOLER BOX.....	B0.06.12
SPIN-ON FILTER.....	B0.06.13
SPIN-ON FILTER.....	B0.06.14
FUEL INJECTION SYSTEM	
FASTENINGS.....	B0.07.0
FASTENINGS.....	B0.07.1
ADD-ON PARTS ENGINE.....	B0.07.2
FUEL LINE.....	B0.07.3
DISTRIBUTOR.....	B0.07.4
FUEL PUMP.....	B0.07.5
FUEL FEED PUMP.....	B0.07.6

HIGH PRESSURE PIPE.....	B0.07.7
FASTENINGS.....	B0.07.8
ENGINE FUEL PUMP.....	B0.07.9
FUEL FEED PUMP.....	B0.07.10
HIGH PRESSURE PIPE.....	B0.07.11
FUEL INJECTOR.....	B0.07.12
FUEL FEED PUMP.....	B0.07.13
ADD-ON PARTS ENGINE.....	B0.07.14
FUEL PUMP.....	B0.07.15
ROLLER TAPPET.....	B0.07.16
FUEL FILTER.....	B0.07.17
DISTRIBUTOR.....	B0.07.18
FUEL LINE.....	B0.07.19
FUEL LINE.....	B0.07.20
FUEL PUMP.....	B0.07.21
OVERFLOW OIL LINE.....	B0.07.22
OVERFLOW OIL LINE.....	B0.07.23
DISTRIBUTOR.....	B0.07.24
ENGINE FUEL PUMP.....	B0.07.25
COMMON RAIL.....	B0.07.26
ROLLER TAPPET.....	B0.07.27
DISTRIBUTOR.....	B0.07.28
MECHANICAL - ELECTRONIC GOVERNOR	
ELECTRONIC CONTROL UNIT - ENGINE.....	B0.08.0
CLOSING COMPONENTS.....	B0.08.1
ELECTRONIC CONTROL UNIT - ENGINE.....	B0.08.2
COOLING	
FASTENINGS.....	B0.09.0
FASTENINGS.....	B0.09.1
FASTENINGS.....	B0.09.2
FASTENINGS.....	B0.09.3
THERMOSTAT.....	B0.09.4
BELT STRETCHER.....	B0.09.5
LUEFTERLAGERUNG.....	B0.09.6
COOLING WATER PIPE.....	B0.09.7
HEATER CONNECTION.....	B0.09.8
MANIFOLD.....	B0.09.9
MANIFOLD.....	B0.09.10
MANIFOLD.....	B0.09.11
MANIFOLD.....	B0.09.12
LUEFTERLAGERUNG.....	B0.09.13
BELT STRETCHER.....	B0.09.14
V-BELT.....	B0.09.15
V-BELT.....	B0.09.16

V-GROOVED PULLEY.....	B0.09.17
CONNECTION.....	B0.09.18
INTAKE - EXHAUST MANIFOLDS	
RELAY.....	B0.10.0
EXHAUST PIPE.....	B0.10.1
ANSCHLUSSKRUEMMER.....	B0.10.2
FASTENINGS.....	B0.10.3
SEALING.....	B0.10.4
MANIFOLD.....	B0.10.5
CLOSING COMPONENTS.....	B0.10.6
GLOW PLUG.....	B0.10.7
GLOW PLUG.....	B0.10.8
CHARGED AIR MANIFOLD.....	B0.10.9
TURBOCHARGER	
TURBOCHARGER.....	B0.11.0
RETURN LINE.....	B0.11.1
OIL LUBRICATION PIPE.....	B0.11.2
OIL LUBRICATION PIPE.....	B0.11.3
CLOSING COMPONENTS.....	B0.11.4
CLOSING COMPONENTS.....	B0.11.5
Electrical accessories	
FASTENINGS.....	B0.12.0
FASTENINGS.....	B0.12.1
COVER PLATE.....	B0.12.3
FASTENINGS.....	B0.12.4
ACCESSORIES.....	B0.12.5
KABELBAUM.....	B0.12.5
STARTER.....	B0.12.6
IMPULSETRANSMITTER.....	B0.12.8
GENERATOR.....	B0.12.9
TEMPER.TRANSMITTER.....	B0.12.10
KABELBAUM.....	B0.12.10
ACCESSORIES.....	B0.12.11
ACCESSORIES.....	B0.12.13
ENGINE MOUNTING.....	B0.12.14
DRIVING PARTS.....	B0.12.15
ACCESSORIES.....	B0.12.17
GENERATOR.....	B0.12.18
STARTER.....	B0.12.20
ACCESSORIES.....	B0.12.21
STARTER.....	B0.12.22
GENERATOR.....	B0.12.23
GENERATOR.....	B0.12.24
ACCESSORIES.....	B0.12.25

ACCESSORIES.....	B0.12.27
ACCESSORIES.....	B0.12.28
ACCESSORIES.....	B0.12.29
ACCESSORIES.....	B0.12.30
ACCESSORIES.....	B0.12.31
OIL PRESSUR.SWITCH.....	B0.12.32
OIL PRESSUR.SWITCH.....	B0.12.33

AGROTRON L720

Ref: B0.00.0 (1)

Section: B0 - ENGINE


ENGINE

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AGROTRON L720]

1	25007693	1	engine EURO III ON ORDERING PLEASE ENGINE NO. REQUIRED
---	----------	---	--



9_N9719_01_0-A-001

AGROTRON L720

Section: B0 - ENGINE

Ref: B0.01.0

FASTENINGS

Fig.	P/n	QTY	Name
Notes: [AGROTRON L720]			
Engine serial number: 10281638 10281639 10281640 10281641 10282374 10309175 10311569 10311570 10312552 10336758 10336759 10336760 10336761 10336762 10342939 10361910 10361911 10361912 10361913 10361914 10514293 10514294 10514295 10514296 10514297 10514298 10514299 10514300 10521147 10521148 10521149 10521150 10521151 10537209 10537210 10537211 10537212 10537213 10537214 10537215 10537216 10584472 10584474 10584475 10584477 10586489 10586493 10586494 10598039 10598040 10598041 10598042 10598043 10598045 10598046 10598047 10598048 10598049 10598050 10598153 10598154 10598971 10598972 10598973 10598974 10598975 10598976 10598977 10598978 10598979 10598980 10598981 10598982 10598983 10600576 10611270 10611271 10611272 10616446 10616448 10616449 10616450 10636157 10654551 10664003 10664004 10664005 10670282 10670283 10679750 10679753 10679754 10679757 10679758 10679759 10679760 10679761 10684484 10684493 10690693 10690696 10690698 10690699 10690700 10694917 10694920 10711025 10711028 10711029 10716353 10716355 10716357 10716359 10741415 10741416 10741418 10741419 10741420 10741424 10741427 10743204 10743206 10743207 10743211 10743212 10743213 10743218 10745241 10745243 10792713 10794030			
[001]©			
3	04910582	1	gasket
4	01143362	14	screw 5 Nm, 30 Nm consult workshop manual 5 Nm, 21 Nm consult workshop manual
5	01181406	1	bushing EN 1662 -F-M8X35-10.9-A4C H 2341 -B11X8-FE/ZN12C*

