



PARTS MANUAL

AGROSTAR TG 6.81

TRACTOR

PRINTED BY :
heavy-equipmentmanual.com

AgroStar TG 6.81

BRAKE

Control assy./servise brake, Parking brake

PARKING BRAKE - PARTS SET..... 13.29.0

PARKING BRAKE - PARTS SET..... 13.29.1

OPERATION - PARKING BRAKE..... 13.29.2

Service brake, Contral assy./service brake

SERVICE BRAKE..... 13.30.0

OPERATION - SERVICE BRAKE..... 13.30.1

BRAKE OPERATION..... 13.30.2

BRAKE OPERATION - SERVICE BRAKE..... 13.30.3

BRAKE OPERATION..... 13.30.4

BRAKE OPERATION..... 13.30.5

Pneumatic system

PRESSURE GAUGE..... 13.55.0

AIR RESERVOIR - PRESSURE REGULATOR..... 13.55.1

CONTROL VALVE - SOLENOID VALVE..... 13.55.2

AIR BRAKE HOSE COUPLING..... 13.55.3

PLASTIC PIPE..... 13.55.4

PIPING..... 13.55.5

BRAKE LINE FRONT/REAR..... 13.55.6

COMPRESSED-AIR UNIT..... 13.55.7

TRAILER SOCKET-OUTLET VALVE..... 02382049.4.A

Hydr. brake for trailer

HYDR. BRAKE TRAILER..... 13.56.0




FESTSTELLBREMSE
PARKING BRAKE
FREIN D'ARRET
FRENO ESTACIONAM.

TEILESATZ
SET OF PARTS
LOT DE PIECE
JUEGO DE PIEZAS

1418-29 0504 6475

3



AgroStar TG 6.81

Section: BRAKE

Ref: 13.29.0

PARKING BRAKE - PARTS SET

Fig.	P/n	QTY	Name
Notes:			
[AgroStar TG 6.81]			
1	04395347	1	pressure plate ring
2	04395348	2	brake lining
3	04395349	4	brake disc
4	04395350	3	brake lining
5	04395351	1	cover
6	04395352	2	pin
7	04395353	2	split pin
8	01112447	6	screw m 10 x 40 DIN 000933-M10 X 40 - 8.8-A4C
9	04402459	1	lever FROM FIRST REPLACEMENT UNTIL FG-NO. SUPPLY WITH ITEM 40
10	04395355	1	square
12	01112407	2	screw m 10 x 20, d933 DIN 000933-M10 X 20 - 8.8-A4C
15	04402686	1	cover
23	04395373	1	oil seal
24	04395314	1	plug
25	04395375	2	stud bolt
26	01117869	12	lock washer DIN 006797-A10,5-A4C
27	01102659	2	nut m 10, d934 DIN 000934-M10 - 8-A4C
28	04395376	1	oil seal
29	04395377	1	shoulder ring
30	04395262	1	circlip
31	04395379	1	lever
33	01112461	2	screw m 10 x 55, d933 DIN 000933-M10 X 55 - 8.8-A4C
37	01144593	2	screw DIN 000933-M10 X 60 - 8.8
40	04402458	1	circlip


Section: BRAKE

PARKING BRAKE - PARTS SET

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AgroStar TG 6.81]



12	04395380	1	oil seal
13	04395381	1	oil seal
14	04395382	1	shim
15	04395383	2	shoulder ring
16	04395384	2	shoulder ring
17	04395385	1	shoulder ring
18	04395386	1	ball bearing
19	04395387	1	ball bearing
20	04395388	1	spacer
21	04395389	1	circlip
22	04395390	1	nut
23	04395356	1	shaft
24	04395357	1	support
25	04395358	1	shoulder ring
26	04395359	1	oil seal
27	04395360	1	spring
28	04395361	1	spring
29	04395362	1	oil seal
30	04395363	1	piston
31	04395364	1	oil seal
32	04395365	1	oil seal
33	04395366	1	shoulder ring
34	04395367	6	ring
35	04395368	6	ring
36	04395369	1	clutch housing
37	04395370	2	oil seal
38	04395371	1	ring
42	04395372	1	gear
48	04402685	1	ring




BETAETIGUNG
CONTROL ASSEMBLY
CDE D'ACTIONNEM.
MANDO ACCIONAMIENTO

FESTSTELLBREMSE
PARKING BRAKE
FREIN D'ARRET
FRENO ESTACIONAM.

1101-29 0504 6437

1




AgroStar TG 6.81

Section: BRAKE

Ref: 13.29.2

OPERATION - PARKING BRAKE

Fig.	P/n	QTY	Name
Notes: [AgroStar TG 6.81]			
2	01129110	1	screw m 8 p.1.25 x 20 DIN 000933-M 8 X 20 SB- 8.8-A 4C
3	04390613	1	console
4	04390598	1	toothed sector
5	01129112	1	screw DIN 000933-M 8 X 25 SB- 8.8-A 4C
7	01107548	2	washer 8.4 DIN 000433- 8,4-140HV-A4C
8	04387530	1	pin
10	01176134	1	key-pin H 002205-L10 -FE/ZN12CC
11	04399542	1	spring
12	01175755	1	switch
14	04390113	1	rod
19	04399547	1	pin
21	04338398	1	spring
22	04338409	1	push-button
24	01107101	4	washer 8.4 DIN 000125-A 8,4-140HV-A4C
25	04365615	1	grip
26	04364731	1	special bearing
27	01177172	1	pin H 002707-A 8X21-ST-A4C
28	01117928	1	washer DIN 006799- 6
31	04394561	1	ball joint
32	04394562	1	pin
33	01113158	1	nut m12x1,5 d936 DIN 000936-M12X1,5 -22H-A4C
35	04386844	1	ratchet
37	04390679	1	lever
38	04390644	1	rod
39	04391359	1	spring
40	01115418	3	pin ISO 008752- 4 X 18



Section: BRAKE
SERVICE BRAKE

AgroStar TG 6.81

Ref: 13.30.0

Fig.	P/n	QTY	Name
Notes:			
[AgroStar TG 6.81]			
1	04395468	1	flange
2	04395469	4	brake disc
3	04395470	2	piston
4	04395471	2	oil seal
5	04395472	2	oil seal
6	04395473	1	box
8	04395474	28	nut
9	04395475	2	disc
10	04395476	2	plug
11	04395477	6	pin
12	01102696	28	lock washer
13	04395478	2	screw
14	04395479	2	screw
15	04395480	2	plug
16	04395481	1	screw
17	04394439	1	oil seal
18	04395483	1	box
19	04395484	26	screw
22	04396801	4	pin

Section: BRAKE

OPERATION - SERVICE BRAKE

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AgroStar TG 6.81]




BETAETIGUNG
CONTROL ASSEMBLY
CDE D'ACTIONNEM.
MANO ACCIONAMIENTO


BETRIEBSBREMSE
BRAKE
FREIN DE SERVICE
FRENO

1101-30 0504 6066

3



1	04392006	1	pedal
2	04384853	1	pedal
3	04396017	4	bushing
5	04386678	3	washer
6	04396019	1	shaft
7	01143330	1	pin
			ISO 008750- 5 X 40-ST
8	04384857	1	spring
9	04384858	1	pin
10	04388562	1	pin
20	04384849	2	bushing
24	04384850	2	contact surface m 8 x 25
25	01112824	2	nut m 8, d934
			ISO 004032-M 8 - 8-A4C
31	01175755	2	switch
53	04388568	4	oil seal




AgroStar TG 6.81

Section: BRAKE

Ref: 13.30.2

BRAKE OPERATION

Fig.	P/n	QTY	Name
Notes: [AgroStar TG 6.81]			
13	04394490	2	cylinder
14	01112322	4	screw m 8 p.1.25 x 20 ISO 004017-M 8 X 20 - 8.8-A4C
15	01103826	4	washer DIN 000125-A 8,4-200HV-A4
16	01119611	4	ring DIN 007980- 8-FST-A4C
18	01114714	2	pin DIN 001434-12F 8X 35X 30 -ST5 0-2-ZNPHRF
19	01107110	2	washer 13.5 DIN 000125-A13 -140HV-A4C
20	01175723	2	split pin H 002470-A12X4 -FE/ZN12CC
22	04394653	2	screw
23	04394654	1	screw
24	04394493	1	screw
25	01118675	4	ring 12 x16 DIN 007603-A 12 X 16 -CU
26	02317786	1	switch
28	04394494	1	small tank
29	04394495	1	cover
30	04394496	1	plate
31	04386550	1	bracket
32	04383959	1	bracket
33	04388546	1	bracket
34	01112240	2	screw m 6 x 12 ISO 004017-M 6 X 12 - 8.8-A4C
35	01119635	2	screw ISO 007045-M 6X 16 - 4.8-H -A 4C
36	01103550	4	washer DIN 000125-A 6,4-200HV-A4
37	01119609	2	spring washer DIN 007980- 6-FST-A4C
38	01112813	2	nut m 6 DIN 000934-M 6 - 8-A4C
39	04388563	2	flexible hose
40	04388561	2	bracket
41	04386547	2	bush
42	04394492	1	tube



BRAKE OPERATION

Fig.	P/n	QTY	Name
50	04394486	1	ball joint
51	01112824	1	nut m 8, d934 ISO 004032-M 8 - 8-A4C



BREMSBETAETIGUNG
BRAKE CONTROL
ACTIONNEMENT FREIN
ACCIONAMIENT. FRENO

BETRIEBSBREMSE
BRAKE
FREIN DE SERVICE
FRENO

1118-30 0504 6520

1

AgroStar TG 6.81

Section: BRAKE

Ref: 13.30.3

BRAKE OPERATION - SERVICE BRAKE

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[AgroStar TG 6.81]

1	04397068	1	tube
2	04397067	1	tube
3	04357219	1	spacer 13x18.5
4	04357320	1	fan
5	01216315	2	rubber plug
6	04344166	1	clamp
7	01124457	2	screw m 8 x 45 ISO 004017-M 8 X 45 - 8.8-A4C

