



PARTS MANUAL

AGROCOMPACT F75

(24-28)

TRACTOR

PRINTED BY :
heavy-equipmentmanual.com

Agrocompact F75 (24"-28")

ACCESSORIES

GENERAL

AUXILIARY FRONT HYDRAULIC DISTRIBUTOR WITH 4 OIL WAYS - FOR MODELS WITHOUT CAB.....	0E.00.0
PIPES FOR 6-WAY FRONT CONTROL VALVE - FOR MODELS WITH CAB.....	0E.00.8
4-WAY AUXILIARY DISTRIBUTOR.....	0E.00.15
CONTROLS FOR 4-WAY FRONT AUXILIARY SERVICES CONTROL VALVE.....	0E.00.16
KNOBS FOR 4-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.23
6-WAY AUXILIARY DISTRIBUTOR.....	0E.00.24
6-WAY AUXILIARY DISTRIBUTOR.....	0E.00.31
6-WAY AUXILIARY DISTRIBUTOR.....	0E.00.32
BRACKETS FOR 6-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.39
4-WAY AUXILIARY DISTRIBUTOR.....	0E.00.40
6-WAY AUXILIARY DISTRIBUTOR.....	0E.00.47
6-WAY AUXILIARY DISTRIBUTOR.....	0E.00.48
4 - 6 - WAY DISTRIBUTOR EQUIPMENT.....	0E.00.55
4 - 6 - WAY DISTRIBUTOR EQUIPMENT.....	0E.00.56
CONTROLS FOR 4-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.64
CONTROLS FOR 4-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.71
CONTROLS FOR 4-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.72
CONTROLS FOR 6-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.87
CONTROLS FOR 6-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.88
CONTROLS FOR 6-WAY AUXILIARY SERVICES CONTROL VALVE.....	0E.00.95
6-WAY AUXILIARY DISTRIBUTOR WITH ELECTRONIC LIFT.....	0E.00.96
6-WAY AUXILIARY DISTRIBUTOR WITH ELECTRONIC LIFT.....	0E.00.103
6-WAY AUXILIARY DISTRIBUTOR WITH ELECTRONIC LIFT.....	0E.00.104
THREE-POINT COUPLING - TOP/LOWER LINK.....	0E.00.111
THREE-POINT COUPLING - TOP/LOWER LINK - AUTOM.....	0E.00.112
THREE-POINT COUPLING - TOP/LOWER LINK - AUTOM. - FOR NARROW CRAMER TOW HOOK.....	0E.00.119
3 POINT HITCH.....	0E.00.120
3 - POINT HITCH - ADJUSTABLE RH RODS.....	0E.00.127
3-POINT HITCH - ADJUSTABLE RH RODS - FOR NARROW CRAMER TOW HOOK.....	0E.00.128
3-POINT HITCH WITH HYDRAULIC LIFT ROD.....	0E.00.135
3-POINT HITCH WITH ELECTRO-HYDRAULIC ADJUSTMENT.....	0E.00.136
3-POINT HITCH WITH ELECTRO-HYDRAULIC ADJUSTMENT.....	0E.00.143
3-POINT HITCH WITH ELECTRO-HYDRAULIC ADJUSTMENT.....	0E.00.144
3-POINT HITCH WITH ELECTRO-HYDRAULIC ADJUSTMENT - FOR NARROW CRAMER TOW HOOK.....	0E.00.151
TOWING BAR 2 cat.....	0E.00.152
REAR OSCILLATING HITCH.....	0E.00.159
REAR TOWING HITCH CAT: "C".....	0E.00.160
FRAME HOOK HOLDER.....	0E.00.167
FRAME HOOK HOLDER GRASSI.....	0E.00.168
REAR TOWING HITCH.....	0E.00.176


REAR TOWING HITCH.....	0E.00.184
REAR TOWING HITCH.....	0E.00.191
REAR TOWING HITCH CAT: "C" GRASSI.....	0E.00.192
REAR TOWING HITCH SCHARMULLER.....	0E.00.199
REAR TOWING HITCH CAT: "D" GRASSI.....	0E.00.200
REAR TOWING HITCH CAT: "D".....	0E.00.207
REAR TOWING HITCH CAT: "D2" GRASSI.....	0E.00.208
REAR TOWING HITCH CAT: "D2".....	0E.00.215
REAR TOWING HITCH CAT: "D2".....	0E.00.216
FRONT TOWING HITCH.....	0E.00.223
FRONT BALLAST n. 8.....	0E.00.224
FRONT WEIGHT CARRIER.....	0E.00.231
FRONT PLATE FOR IMPLEMENTS.....	0E.00.232
FRONT BALLAST KG. 250.....	0E.00.239
BALLAST LOCK BAR.....	0E.00.240
HYDRAULIC BREAKING FOR TRAILER - ITALY -.....	0E.00.244
HYDRAULIC BREAKING FOR TRAILER - EXPORT F.....	0E.00.245
HYDRAULIC TRAILER BRAKING PARTS KIT.....	0E.00.246
HYDRAULIC TRAILER BRAKING PARTS KIT.....	0E.00.247
HYDRAULIC BREAKING FOR TRAILER.....	0E.00.248
HYDRAULIC BREAKING FOR TRAILER.....	0E.00.249
HYDRAULIC BREAKING FOR TRAILER.....	0E.00.250
LUBRICATOR.....	0E.00.251
TOOL POUCH.....	0E.00.252
VALVE PARTS.....	0.009.9778.4.A
TOWING HITCH.....	0.010.1702.3.A
CYLINDER PARTS.....	0.011.3468.4/10.A
DRAWBAR COUPLING.....	0.011.3636.4/30.A
3 - POINT HITCH - ADJUSTABLE RH RODS.....	0.011.3988.3.A
CYLINDER PARTS.....	0.011.4904.4.A
REAR TOWING HITCH CAT: "D" GRASSI.....	0.011.5143.4/10.A
DRAWBAR COUPLING CAT: "D2".....	0.011.5144.4.A
CYLINDER PARTS.....	0.011.5363.4.A
DRAWBAR COUPLING.....	0.012.2216.4.A
LINKAGE.....	0.014.1412.3.A
TOWING HITCH.....	0.014.1420.3.A
REAR TOWING HITCH CAT: "D".....	0.014.4451.3.A
DRAWBAR COUPLING CAT: "D2".....	0.014.4452.3/10.A
DRAWBAR COUPLING D2.....	0.014.4461.3.A
DRAWBAR COUPLING.....	0.014.4470.4.A
SLIDE.....	0.014.8203.3/10.A
REAR TOWING HITCH CEE.....	0.014.8209.3.A
CHASSIS.....	0.014.8232.3.A
ENGAGEMENT.....	0.98308.50.3/10.A

ENGAGEMENT.....	0.98309.50.3/10.A
TRAILER BRAKE VALVE.....	2.3719.550.0/40.A
HYDRAULIC DISTRIBUTOR-PARTS.....	2.3719.730.0/10.A
HYDRAULIC DISTRIBUTOR-PARTS.....	2.3719.740.0/20.A
VALVE PARTS.....	2.3719.810.0/10.A
SOLENOID VALVE.....	2.3729.330.0/40.A
SOLENOID VALVE.....	2.3729.340.0/40.A
DISTRIBUTOR.....	2.3729.500.0.A
CYLINDER PARTS.....	2.3749.003.0.A

AUXILIARY FRONT HYDRAULIC DISTRIBUTOR WITH 4 OIL WAYS - FOR MODELS WITHOUT CAB

[Agrocompact F75 (24"-28")]

2	2.3261.009.2	2	pipe fitting m 18 p.1.5-3/4"
3	0.009.3149.0	6	plug
4	0.98309.51.3/10	6	coupling 1/2
5	2.1560.054.0	6	gasket 21 x 26
9	2.1549.089.2	1	spacer 18.6x25x30
10	2.1560.014.0	10	washer 18.2 x 24
11	2.3335.008.2	1	pipe union m 18 p.1.5 x 32
12	0.010.9453.3/10	1	tube
13	0.010.9452.3	1	tube
14	0.010.9454.3	1	tube
15	0.010.9455.3	1	tube
16	0.010.9457.3/20	1	tube
17	0.010.9456.3/20	1	tube
18	0.010.9538.3/10	2	bracket
19	0.010.9537.0	1	bracket
20	0.009.8707.0	3	clamp
21	2.0112.007.2	6	screw m 6 p.1 x 20
22	0.154.6377.3	1	terminal
23	2.1011.103.2	1	nut m 6 p.1
24	2.0112.211.2	6	screw m 8 p.1.25 x 30
25	2.1579.987.2	6	spacer 8.5x16x8
26	2.1011.105.2	6	nut m 8 p.1.25
28	2.3339.111.2	1	pipe union
45	2.1099.145.2/10	1	special nut m 18 p.1.5
53	0.010.9462.3/20	1	tube
54	0.010.9460.3/20	1	tube
55	0.010.9461.3/10	1	tube
59	2.1579.936.2	1	spacer 19x25x20



Agrocompact F75 (24"-28")

Ref: 0E.00.8

Section: ACCESSORIES

PIPES FOR 6-WAY FRONT CONTROL VALVE - FOR MODELS WITH CAB




Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[Agrocompact F75 (24"-28")]

2	0.011.2626.3/10	1	tube
3	0.009.3149.0	6	plug
4	0.98309.51.3/10	6	coupling 1/2
5	2.1560.054.0	6	gasket 21 x 26
9	0.011.2627.3/10	1	tube
10	2.1560.014.0	13	washer 18.2 x 24
11	2.3335.008.2	2	pipe union m 18 p.1.5 x 32
12	0.011.2623.3	1	tube
13	0.011.2624.3	1	tube
14	0.011.2669.3	1	tube
15	0.011.2668.3	1	tube
16	0.011.2628.3/10	1	tube
17	0.011.2629.3/10	1	tube
18	0.011.3562.0	1	bracket
19	0.010.9537.0	1	bracket
20	0.009.8707.0	2	clamp
21	2.0112.007.2	6	screw m 6 p.1 x 20
22	0.154.6377.3	1	terminal
23	2.1011.103.2	1	nut m 6 p.1
24	2.0112.613.2	1	screw m 16 p.2x35
25	2.1475.006.2	1	spring washer 16
26	0.011.2640.0	1	bracket
45	2.1099.145.2/10	1	special nut m 18 p.1.5
53	0.011.2632.3	1	tube
54	0.011.2625.3/10	1	tube
55	0.012.0124.3	1	tube
59	2.1579.936.2	1	spacer 19x25x20
73	2.1549.089.2	2	spacer 18.6x25x30
74	2.3339.585.2/20	2	pipe union m 18 p.1.5x66
76	0.011.4325.2/10	1	plate dx/rh/re
77	2.1475.005.7	1	washer 14
78	2.0112.515.2	1	screw m 14 p.2 x 40
79	2.1475.006.2	2	spring washer 16
80	2.0112.615.2	2	screw m 16 p.2 x 40

Ref: 0E.00.15

Fig.	P/n	QTY	Name
------	-----	-----	------

[Agrocompact F75 (24"-28")]

1	2.3719.730.0/10	1	spool valve
			COMPONENT PARTS SEE COMPONENTS LIST
			☞ 2.3719.730.0/10
6	2.0312.216.2	3	screw m 8 p.1.25x50
7	2.1310.004.2	3	flat washer 8.4x17
8	2.1011.105.2	4	nut m 8 p.1.25
10	2.1560.014.0	10	washer 18.2 x 24
11	2.3335.008.2	3	pipe union m 18 p.1.5 x 32
12	2.1560.018.0	6	gasket 22.2 x 29
13	2.3319.062.2/20	3	pipe union m 22 p.1.5x32
14	0.011.9564.3	1	tube
15	0.011.9567.3	1	tube
16	0.011.9574.3	1	pipe fitting
17	0.012.5909.2	1	plate
18	2.0112.013.2	1	screw m 6 p.1 x 35
19	2.1480.012.2	4	washer 6, d128
22	2.1470.002.2	8	lock washer 6
23	2.1011.103.2	8	nut m 6 p.1
24	0.011.9569.3	1	tube
27	2.3261.115.2	1	pipe fitting 3/8 gas - 7/8"
30	2.3339.485.2/10	1	pipe union m 18 p.1.5x55
31	2.1560.053.0	2	gasket 17 x 21
32	2.1569.160.0	1	gasket 18.2x22x3.5
39	0.010.9465.3	1	tube
42	0.010.9466.3	1	tube
43	0.014.0449.3/10	1	tube
44	0.010.9467.3	1	tube
45	2.1099.145.2/10	1	special nut m 18 p.1.5
48	2.0312.105.2	4	screw m 6 p.1 x 18
50	2.1531.052.0	1	oil seal 20.29 x 2.62
51	0.012.5927.3	1	tube
52	0.010.9464.3	1	tube
56	0.010.9459.3/10	1	tube
57	0.010.9458.3	1	tube
62	0.010.9536.3	1	bracket
63	0.154.6377.0	15	terminal
64	2.1310.010.2	1	flat washer 17x30
65	2.0112.605.2	1	screw m 16 p.2x16
66	2.0112.011.2	1	screw m 6 p.1x30
67	2.0112.009.2	7	screw m 6 p.1 x 25
70	0.009.9778.4	1	valve



Section: ACCESSORIES

4-WAY AUXILIARY DISTRIBUTOR


Fig.	P/n	QTY	Name
------	-----	-----	------

COMPONENT PARTS SEE COMPONENTS LIST

0.009.9778.4

71 2.1549.385.2 1 spacer 18.6 x 25 x 13

91 0.445.6388.3/10 1 valve



9_D6088_05_0_0

Agrocompact F75 (24"-28")

Ref: 0E.00.16

Section: ACCESSORIES


CONTROLS FOR 4-WAY FRONT AUXILIARY SERVICES CONTROL VALVE

Fig.	P/n	QTY	Name
------	-----	-----	------


Notes:

[Agrocompact F75 (24"-28")]

1	0.009.1749.0/20	2	control
2	0.010.1161.0	1	lever
3	2.0112.005.2	4	screw m 6 p.1 x 16
4	0.010.1162.0	1	lever
5	2.1549.327.2	1	spacer 9X16X50
6	2.1470.004.2	1	lock washer 8
7	2.0312.219.2	1	screw m 8 p.1.25x65
8	2.4049.160.2	2	spring
9	0.010.1154.3	1	support
10	2.1470.002.2	4	lock washer 6
11	2.0112.003.2	4	screw m 6 p.1 x 12
12	0.010.4279.3/50	2	rod
13	2.1474.007.2	4	washer 6, d128
14	2.0312.106.2	4	screw m 6 p.1 x 20
15	2.6569.054.0	1	rubber plug
16	0.010.9059.0	1	support



9_70588_31_0_0



Agrocompact F75 (24"-28")

Section: ACCESSORIES

Ref: 0E.00.23

KNOBS FOR 4-WAY AUXILIARY SERVICES CONTROL VALVE

Fig.	P/n	QTY	Name
Notes:			
[Agrocompact F75 (24"-28")]			
1	0.008.8388.0	2	knob
2	0.009.0140.0	2	coupling GREY