



PARTS MANUAL

DXAB 90 TRACTOR

PRINTED BY :
heavy-equipmentmanual.com

DXab 90

BRAKE

Control assy./service brake, Parking brake

HAND BRAKE.....	13.29.0
OPERATION - P.T.O. SHAFT - REAR.....	13.29.5
OPERATION - P.T.O. SHAFT - REAR.....	13.29.8

Service brake, Contral assy./service brake

OPERATION - P.T.O. SHAFT - REAR.....	13.30.16
OPERATION - P.T.O. SHAFT - REAR.....	13.30.17
OPERATION - P.T.O. SHAFT - REAR.....	13.30.29
OPERATION - P.T.O. SHAFT - REAR.....	13.30.30
OPERATION - P.T.O. SHAFT - REAR.....	13.30.35
SERVICE BRAKE - DISC BRAKE.....	13.30.38
SERVICE BRAKE - DISC BRAKE.....	13.30.39

Pneumatic system


COMPRESSED-AIR UNIT.....	13.55.12
COMPRESSED-AIR UNIT.....	13.55.13
COMPRESSED-AIR UNIT.....	13.55.14
COMPRESSED-AIR UNIT.....	13.55.15
COMPRESSED-AIR UNIT.....	13.55.16
COMPRESSED-AIR UNIT.....	13.55.17

Hydr. brake for trailer

HYDR. BRAKE.....	13.56.6
HYDR. BRAKE.....	13.56.8

**DEUTZ
FAHR** FESTSTELLBREMSE
PARKING BRAKE
FREIN D'ARRET
FRENO ESTACIONAM.

1405-29 503 6354



Section: BRAKE
HAND BRAKE

DXab 90

Ref: 13.29.0

Fig.	P/n	QTY	Name
Notes: [DXab 90]			
2	04313463	1	lever LEFT
3	04313468	1	lever RIGHTS
6	04357790	12	screw
7	04378717	2	brake disc
12	02386814	1	shaft
13	02386813	1	bushing
14	01161357	2	oil seal H 002927- 22 X 2 -NBR-1-60
15	02386815	1	washer
16	01107730	1	ring 20 x 1.2, d471 DIN 000471- 20X1,2
17	02386817	2	spring
20	04378793	2	brake shoe
22	04324306	1	plate
33	01118463	10	rivet DIN 007338-B 4X10-MS
35	04378793	1	brake shoe
41	04313624	2	brake disc

DXab 90

Section: BRAKE

Ref: 13.29.5


OPERATION - P.T.O. SHAFT - REAR

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:


[DXab 90]

2	04313479	1	shaft
3	04337681	1	brake lever
4	04337688	1	brake lever
5	04303825	1	console
6	04313480	2	ring
7	04313486	2	tensioner
8	04346709	2	rod
9	04313482	2	rod
10	01151578	2	nut
11	01122501	2	nut
			DIN 000936-M12 -04
			DIN 000936-M12 LH -17H-A4C
			LEFT-HAND THREAD
12	03387776	4	pin
13	01107110	4	washer 13.5
			DIN 000125-A13 -140HV-A4C
14	01107138	2	washer 31x56x5 d125
			DIN 000125-B31 -140HV-A4C
15	01172606	2	oil seal
			H 002940-AS 30X 40 X 7 -NI
16	01102527	2	pin
			ISO 008752-10 X 50
17	01117930	1	washer
			DIN 006799- 9
18	01112429	3	screw m 10 x 30, d933
			DIN 000933-M10 X 30 - 8.8-A4C
19	01102800	3	washer 10.2
			DIN 000128-A 10 -FST -A4C
21	01112326	3	screw m 8 x 22
			ISO 004017-M 8 X 22 - 8.8-A4C
22	01107101	3	washer 8.4
			DIN 000125-A 8,4-140HV-A4C
23	04313956	1	plate
24	01171734	4	screw
			H 002093- 7985-M 6X 16 -4.8 -
			H
25	01115461	2	roll pin
			ISO 008752- 6 X 50
26	04324313	1	handbrake lever
33	04306345	1	console
34	02320979	1	spring



OPERATION - P.T.O. SHAFT - REAR


Fig.	P/n	QTY	Name
35	02320980	1	ratchet
36	01104443	1	pin DIN 001434- 8F 8X 45X 42 -ST5 0-2-A4C
37	02320978	1	support
38	01106407	1	split pin DIN 000094- 2 X 14-ST-A4C
39	01107548	1	washer 8.4 DIN 000433- 8,4-140HV-A4C
41	02324608	1	bush
42	01122674	1	pin ISO 008752- 5 X 18
43	02320982	1	spring
44	04360706	1	pin
45	01115435	2	pin ISO 008752- 5 X 24
46	01115416	2	pin ISO 008752- 4 X 14
48	04313957	1	cover
49	04324314	1	lever



Section: BRAKE


OPERATION - P.T.O. SHAFT - REAR

Fig.	P/n	QTY	Name
Notes:			
[DXab 90]			
1	04337802	1	shaft
5	04359327	1	handbrake lever BESTEHEND AUS POS.....
8	04313486	2	tensioner
9	04313480	2	ring
10	01151578	2	nut DIN 000936-M12 -04
12	01107110	4	washer 13.5 DIN 000125-A13 -140HV-A4C
13	03387776	4	pin
14	01102527	2	pin ISO 008752-10 X 50
15	01115461	2	roll pin ISO 008752- 6 X 50
16	01172606	2	oil seal H 002940-AS 30X 40 X 7 -NI
17	01107138	2	washer 31x56x5 d125 DIN 000125-B31 -140HV-A4C
20	01110645	1	screw m 10 x 16, d912 DIN 000912- M10 X 16 - 8.8-A4 C
21	01119613	1	washer 10.5 DIN 007980-10-FST-A4C
22	01117930	1	washer DIN 006799- 9
23	04338791	1	plate
24	01171734	3	screw H 002093- 7985-M 6X 16 -4.8 - H
25	04337681	1	brake lever
26	04337688	1	brake lever
27	04346709	2	rod
28	04313482	2	rod
31	04337988	1	handle
32	04338790	1	cover
33	04332528	1	tube
34	02320978	1	support
35	02320980	1	ratchet
36	02320979	1	spring
37	04351614	1	bracket
38	01137190	1	pin



OPERATION - P.T.O. SHAFT - REAR

Fig.	P/n	QTY	Name
			ISO 002341-B 8A11X 35X 29 -ST 50-2-A4C
39	01107548	1	washer 8.4
40	01106407	1	DIN 000433- 8,4-140HV-A4C split pin
41	01122674	1	DIN 000094- 2 X 14-ST-A4C pin
42	02320982	1	ISO 008752- 5 X 18 spring
43	04360706	1	pin
44	02324608	1	bush
45	01115435	2	pin ISO 008752- 5 X 24
46	01115416	2	pin ISO 008752- 4 X 14



Section: BRAKE

OPERATION - P.T.O. SHAFT - REAR


Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[DXab 90]


2	04314055	1	container
3	04314109	1	flexible hose
4	04305837	1	pipe fitting 6, d128
5	04305838	1	plug
6	04305839	1	plug
7	04314052	1	square
8	01129104	1	screw m 6 p.1.0 x 16 DIN 000933-M 6 X 16 SB- 8.8-A 4C
9	01126726	1	spring disc b6 d137 DIN 000137-B 6-FST-A4C
10	01112307	4	screw m 8 p.1.25 x 15, d933 ISO 004017-M 8 X 16 - 8.8-A4C
11	04312531	1	hood
13	04311150	1	valve
14	02317786	1	switch
15	01107101	1	washer 8.4 DIN 000125-A 8,4-140HV-A4C
16	01112824	1	nut m 8, d934 ISO 004032-M 8 - 8-A4C
17	04336162	1	pipng
18	04336166	1	pipng
19	04336168	1	pipng
21	04378300	3	shim
71	04355447	1	pedal
72	04327268	1	pedal
73	04368875	2	cylinder
74	02389277	2	tube
75	04336161	1	stop
76	02386821	2	ball joint
77	01113158	2	nut m12x1,5 d936 DIN 000936-M12X1,5 -22H-A4C
78	04349697	2	ferrule
79	01129113	4	screw m 8 x 30 DIN 000933-M 8 X 30 SB- 8.8-A 4C
80	01107101	6	washer 8.4 DIN 000125-A 8,4-140HV-A4C
81	01112307	2	screw m 8 p.1.25 x 15, d933 ISO 004017-M 8 X 16 - 8.8-A4C
82	01235354	2	brace

DEUTZ FAHR
 BETÄTIGUNG CONTROL ASSEMBLY
 CDE D'ACTIONNEM. FREIN DE ROUTE
 ACCIONAMIENTO FRENO DE RODADURA
 HAUPTZYLINDER MAIN CYLINDER
 MAITRE-CYLINDRE CILIND. PRINCIPAL
 7818 / 0393
 7819 / 0494
 1024-30 503 9156



OPERATION - P.T.O. SHAFT - REAR

Fig.	P/n	QTY	Name
83	01107740	1	circlip DIN 000471- 28X1,5
84	01162418	1	washer H 002308-29 X44X2 -A4C
85	01114714	2	pin DIN 001434-12F 8X 35X 30 -ST5 0-2-ZNPHRF
86	01107110	2	washer 13.5 DIN 000125-A13 -140HV-A4C
87	02386782	1	pin
88	01171750	1	pin H 002498-1470- 8 X 90
89	01115459	1	pin ISO 008752- 6 X 45
90	02386603	1	pin
91	03387776	2	pin
92	04321200	2	bracket
93	04323349	2	spring
102	02962960	1	small mesh
103	04311138	1	screw
104	04302955	2	bushing
105	04382941		sub-assy parts TO ITEM...



Section: BRAKE

OPERATION - P.T.O. SHAFT - REAR

Fig.	P/n	QTY	Name
Notes:			
[DXab 90]			
10	01112307	4	screw m 8 p.1.25 x 15, d933
12	01118659	2	oil seal ISO 004017-M 8 X 16 - 8.8-A4C
16	01112824	1	nut m 8, d934
20	01173478	2	rubber bushing H 002928-F 6 X19 X 3 -GI DEUT Z11
21	04378300	3	shim
22	04336043	1	pipng
23	04336046	1	pipng
24	02383008	1	clamp
25	01129113	1	screw m 8 x 30 DIN 000933-M 8 X 30 SB- 8.8-A 4C
26	01216315	3	rubber plug
27	01121654	4	stop DIN 074225- 14
28	01138718	2	flexible hose DIN 074225-EE10X360
29	04332125	2	socket
30	04325215	2	shim
33	04344166	1	clamp
34	01112350	1	screw m 8 x 35 ISO 004017-M 8 X 35 - 8.8-A4C
35	04336258	2	actuator
36	04315439	1	console
37	01112429	1	screw m 10 x 30, d933 DIN 000933-M10 X 30 - 8.8-A4C
38	01107286	1	spring washer b10 d137 DIN 000137-B10-FST-A4C
40	04315779	1	tube
41	04336237	1	tube
42	04347523	1	tube
43	04336240	1	tube
44	04311530	1	console
45	01121261	1	clamp DIN 072571- 1X15-ST FE/ZN12CC
46	01123746	1	screw ISO 004017-M 5 X 10 - 8.8-A4C

