



PARTS MANUAL

FARMLINER 3370

COMBINE

PRINTED BY :
heavy-equipmentmanual.com

FARMLINER 3370

CAB

OPERATING PLATFORM

DRIVING SEAT.....	4G.13.20000
OPERATING PLATFORM RAILING.....	4G.13.20000
CUTTING TABLE HEIGHT CONTROL.....	4G.13.20000
STEERING COLUMN.....	4G.13.20000
DRIVER'S SEAT.....	4G.13.20000
LUXUR. DRIVER'S SEAT AIR SUSPENSION W.....	4G.13.20000
GEAR SHIFTING.....	4G.13.20000
CONTROL UNIT OPERATION.....	4G.13.20000
CONTROL UNIT OPERAT. GRAIN TANK.....	4G.13.20000
HYDRAULIC BRAKING SYSTEM.....	4G.13.20000
HYDRAULIC BRAKING SYSTEM.....	4G.13.20000
CLUTCH CONTROL ASSEMBLY.....	4G.13.20000
PARKING BRAKE.....	4G.13.20000

DRIVER'S CAB

DRIVER'S CAB FRAME W.....	4G.14.20000
DRIVER'S CAB GLAZING W.....	4G.14.20000
DRIVER'S CAB GLAZING W.....	4G.14.20000
DRIVER'S CAB WINDSCREEN WIPER W.....	4G.14.20000
DRIVER'S CAB ROOF W.....	4G.14.20000
DRIVER'S CAB ROOF / FAN W.....	4G.14.20000

FARMLINER 3370

Ref: 4G.13.20000


Section: CAB

DRIVING SEAT

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[FARMLINER 3370]



1	16020566	1	plate
2	01112307	13	screw m 8 p.1.25 x 15, d933
3	06214192		washer 8.4
4	01104944	5	nut m 8, d985
5	01112322	2	screw m 8 p.1.25 x 20
6	06541291	1	cap
7	06276360		gasket l-3910 130 MM / 1400 MM
8	06541292	1	rail
9	01133175		rivet b4x11x9 d7331
10	01112813	4	nut m 6
11	01102797	6	washer 6, d128
12	06214189	8	washer 6.4
13	06528391	1	cover
14	06257697		copper gasket 15x5x1540 440 MM
15	06546334	1	guard
16	06530285	1	rail
17	06530286	1	rail
19	01102799	10	washer 8, d128
20	06541286	1	division
21	01112529	2	screw m 12 x 30, d933
22	01102801	4	washer 12
23	06214206	10	washer 13.2
24	01112418	9	screw m 10 x 25, d933
25	01107165		washer 10.5
26	06209768	19	nut m 10, d985
27	06535403	1	platform sx/lh/li
28	01136993	2	screw m 12 x 70
29	06536930	2	spacer
30	06209778	2	nut m 12
31	06536928	1	climbing steps
32	06519159	1	plate
33	06261005	2	small cover PVC
34	01112240	2	screw m 6 x 12
35	06518458	4	bracket
36	06515741	4	bearing block
37	06240287	4	rubber mount Ø 14 / Ø 40 x 40
38	06515740	4	bushing 20x57
39	01111545	4	screw m12x90 d931
40	01112429	8	screw m 10 x 30, d933

Section: CAB

DRIVING SEAT




Fig.	P/n	QTY	Name
41	06216517	2	bottom 36.5
42	06523959	1	climbing steps W
43	NE		plate
44	NE		plate
45	06214192	1	washer 8.4 W
46	01143002	1	split pin W
47	06537822	1	rope W
48	06515685	1	terminal W
49	01112276	2	screw m 6 p.1 x 35 W
50	06214189	4	washer 6.4 W
51	01114357	2	nut m 6, d985 W
52	01112575	2	screw m 12 x 65, d933
53	06209769	4	nut m 12, d985

FARMLINER 3370

Section: CAB


Ref: 4G.13.20000

OPERATING PLATFORM RAILING

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[FARMLINER 3370]



1	06535459	1	handrail
2	01112418	9	screw m 10 x 25, d933
3	01102800	2	washer 10.2
4	06535458	1	handrail
FOR MACHINES WITHOUT DRIVER'S CAB			
5	06536954	1	handrail
6	01111200	2	screw m8x90 d931
7	01107163	2	washer 9, d126
8	01104944	2	nut m 8, d985
9	06283014	2	bushing
10	04327533	2	mirror
11	06536951	1	handrail
12	06209768	9	nut m 10, d985
13	01101846	3	screw m 10 x 70, d933
14	06214192	2	washer 8.4
15	06542312	1	support dx/rh/re R
16	06542313	1	support sx/lh/li L

FARMLINER 3370

Section: CAB

Ref: 4G.13.20000


CUTTING TABLE HEIGHT CONTROL

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[FARMLINER 3370]

1	06255042	1	tube
2	06255038	1	rope 2x1200
3	06255036	1	bracket
4	01112803	2	nut m 5, d934
5	06261053	1	screw m5x10,7
6	06215299	1	spring
7	01112232	1	screw m 6 p.1 x 10
8	01114357	1	nut m 6, d985
9	06536933	1	body
10	01141802	1	plate
11	01112341	2	screw m 8 x 30, d933
12	01102799	2	washer 8, d128
13	06258273	2	support
14	06264645	1	eyelet
15	06255040	1	pipe fitting
16	06214192	1	washer 8.4
17	01104944	1	nut m 8, d985



FARMLINER 3370

Section: CAB


Ref: 4G.13.20000

STEERING COLUMN

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[FARMLINER 3370]




1	06256102	1	grip
2	04372644	1	cap
3	01138932	1	nut m 18 p.1.5
4	01102804	1	spring washer a18 d128
5	04309876	1	flywheel
6	06260959	1	shoulder ring 40x23x13
7	06260957	1	top link
8	06214304	1	washer 23x30x1,5
9	01107732	1	circlip
10	01111134	3	screw
11	01104944	3	nut m 8, d985
12	06261071	1	constant-velocity joint
16	01107163	8	washer 9, d126
19	06260961	1	gasket
20	06278997	1	steering column
21	06260960	1	screw
22	06283060	2	bushing
23	06261000	1	cover
24	06261084	1	valve
25	06260946	2	bushing 22x25x15
26	01120692	1	grease gun am 6
27	01097625	1	plug Ø 35 x 12
28	06544838	1	lever
29	06207554	1	screw m 12 x 25
30	06214229	1	washer 21 x 32 x 2.0
31	06214131	8	screw m 6 x 12
32	01126186	2	screw m 10 x 16
33	01107165	2	washer 10.5
34	06214206	1	washer 13.2
35	01112333	8	screw m 8 x 25, d933
36	06214192	8	washer 8.4
37	01104944	7	nut m 8, d985
41	06214461	2	shim 12x18x0,5
42	16027407	1	ashtray
43	01151385	2	screw m 3.5 x 9.5
44	06214477		washer 25 x 35 x 1.0
44.1	06214588		washer 25x35x2
46	06538663	1	hydrostatic B D16
47	06506236	1	steering column
48	06506238	1	console

Section: CAB

Ref: 4G.13.20000

STEERING COLUMN

Fig.	P/n	QTY	Name
49	01112322	4	screw m 8 p.1.25 x 20
50	01102799	4	washer 8, d128
52	01103734	1	screw m8x55 d931-10
55	06528431	1	shaft




Section: CAB

DRIVER'S SEAT

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

POS.NR. 1 - 6 FOR MACHINES WITH DRIVER'S CAB ----- [FARMLINER 3370]



1	16026567	1	seat
2	16000601	1	backrest
2.1	04418264	1	backrest - 0826 / W
3	16000602	1	padding
3.1	04418263	1	padding - 0826 / W
4	16000603	1	guard
4.1	04418343	1	guard - 0826 / W
5	16000604	1	spring
5.1	04311768	1	spring - 0826 / W
6	16000605	1	shock absorber
6.1	04350980	1	shock absorber - 0826 / W
7	16026565	1	small piston + 0827 / W
8	04389284	1	seat
8.1	16031517	1	seat G 8-10
9	04389283	1	backrest kpl.
9.1	16031518	1	backrest - 0826
10	04389125	1	backrest + 0827
10.1	04418963	1	padding
11	01112322	8	padding - 0826
12	06549126	1	padding + 0827
12.1	16033148	1	shock absorber
		1	shock absorber - 0826
		1	shock absorber + 0827
		8	screw m 8 p.1.25 x 20
		1	adapter
		1	adapter - 0826
		1	adapter

Section: CAB

DRIVER'S SEAT

Fig.	P/n	QTY	Name
			+ 0827
13	01107163	4	washer 9, d126
13.1	06214192	4	washer 8.4
14	01104944	8	nut m 8, d985

