



PARTS MANUAL

M 1202 SUPER COMBINE HARVESTER

PRINTED BY :
heavy-equipmentmanual.com

M 1202 SUPER

ENGINE

GENERAL

ENGINE ASSEMBLY PARTS.....	4A.00.20000
MOTOR KURBELGEHAEUSE.....	4A.00.20000
ENGINE OIL PAN.....	4A.00.20000
ENGINE FRONT COVER.....	4A.00.20000
ENGINE COVER WITH IDLER PULLEY.....	4A.00.20000
ENGINE STOP-SWITCH MOUNTING.....	4A.00.20000
ENGINE OIL PUMP.....	4A.00.20000
ENGINE CRANKSHAFT.....	4A.00.20000
ENGINE CYLINDER / PISTON.....	4A.00.20000
ENGINE CYLINDER HEAD.....	4A.00.20000
ENGINE TIMING GEARS.....	4A.00.20000
ENGINE CAMSHAFT.....	4A.00.20000
ENGINE LUBE OIL COOLER.....	4A.00.20000
ENGINE / OIL FILTER FUEL FILTER.....	4A.00.20000
ENGINE INJECTION PUMP.....	4A.00.20000
ENGINE FUEL PUMP.....	4A.00.20000
MOTOR EINSPRITZPUMPE LEITUNGEN.....	4A.00.20000
ENGINE INJECTOR.....	4A.00.20000
ENGINE AIR INTAKE PIPE.....	4A.00.20000
MOTOR KUEHLGEBLAESE.....	4A.00.20000
ENGINE AIR GUIDE.....	4A.00.20000
MOTOR ABGASSCHALLDAEMPFER.....	4A.00.20000
ENGINE GENERATOR.....	4A.00.20000
MOTOR EINZELTEILE DER LICHTMASCHINE.....	4A.00.20000
ENGINE STARTER MOTOR.....	4A.00.20000
MOTOR EINZELTEILE Z. ANLASSER.....	4A.00.20000
ENGINE HYDRAULIC PUMP.....	4A.00.20000
ENGINE SEALING SET.....	4A.00.20000
ENGINE VENTILATION CHANNEL ASSEMBLY PARTS.....	4A.00.20000
OIL DRAINE PIPE BREATHER LINE.....	4A.00.20000
KRAFTSTOFFBEHAELTER.....	4A.00.20000
AIR CLEANER.....	4A.00.20000
ENGINE SPEED ADJUSTING PARTS.....	4A.00.20000


ENGINE ASSEMBLY PARTS

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

MOTOR F 6 L 912 85 KW / 116 PS [M 1202 SUPER]

1	06529983	1	flywheel
2	01104847	10	screw
3	06278905	2	support
4	06529969	1	plate
5	06529966	1	plate sx/lh/li
6	06529976	1	profile
7	06529967	1	plate sx/lh/li
8	01112515	8	screw m 12 x 25
9	01102801	12	washer 12
10	01112547	3	screw m 12 x 40, d933
10	01112554	1	screw m 12 x 45
11	06545014	1	plate
12	06545179	1	exhaust pipe
13	01112299	2	screw m 8 x 12, d933
14	01107163		washer 9, d126
15	01102799	13	washer 8, d128
16	06539397	1	carrier
17	01112824	1	nut m 8, d934
18	01112322	15	screw m 8 p.1.25 x 20
19	01112407	5	screw m 10 x 20, d933
20	01107165	1	washer 10.5
21	06513291	1	pin
22	01111186	1	screw m 8 x 75
23	06284941	1	bracket
24	01126146	4	screw
25	01102802	4	washer 14.2
26	06300827	1	ring
27	06259813	4	brush
28	01139178	8	rivet
29	06216475	2	bracket 280-310/12
30	06539396	1	screw
31	01112264	4	screw m 6 x 20, d933
32	01102797	4	washer 6, d128
33	01112813	4	nut m 6
34	06209768	10	nut m 10, d985
35	01104944	5	nut m 8, d985
36	01112418	10	screw m 10 x 25, d933
37	01102800		washer 10.2
38	06529972	1	chassis frame
39	01120892	1	fascia 70,5 d71555




Section: ENGINE

MOTOR KURBELGEHAEUSE

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[M 1202 SUPER]



1	04156225	1	crankcase
2	04156229	1	cover
3	04156227	6	cover
4	01216107	14	washer 15x23x1,5
5	04160764	14	bushing
6	04156058	14	screw
7	02233347		bearing
7	03362379	7	bearing
7	03362380		bearing
7	03362381		bearing
7	03362382		bearing
7	03362383		bearing
7	03362384		bearing
7	03362385		bearing
8	02139737	1	bushing
9	01215235	7	plug
10	01110422	6	screw
11	01118673	7	oil seal
12	01216240	1	disc
13	01167266	2	bush
14	02230181	1	shim
14	02230182		shim
14	02230183		shim
14	02230184		shim
14	02230185		shim
15	02230170	1	shim
15	02230172		shim
15	02230173		shim
15	02230174		shim
15	02230175		shim
16	02234870	1	cover
17	04152349	1	oil seal
18	03362337	1	gasket
19	01112322	8	screw m 8 p.1.25 x 20
20	01107101	8	washer 8.4
21	02231082	1	plate
22	01115333	2	self tapping screw
23	01214987	2	screw
24	01118727	2	oil seal
27	01118998	5	screw
28	01118659	5	oil seal


M 1202 SUPER

Section: ENGINE

Ref: 4A.00.20000

MOTOR KURBELGEHAEUSE

Fig.	P/n	QTY	Name
29	02239584	6	nozzle
30	01119611	6	ring
31	02139682	1	box
32	01166343	1	clamp
33	01166345	1	band
34	16022140	1	tube
			☞ 4A.00.20000
35	02138266	1	fan
36	01007910		compound 1 kg
37	01178319	1	dipstick
			G 37,88
38	01174311	1	oil seal
39	01167269	1	bush




Section: ENGINE
ENGINE OIL PAN

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:
[M 1202 SUPER]

1	02234521	1	oil sump
3	01216151	1	bushing
4	04157240	1	gasket
5	01102193	26	screw m 8 x 16
6	01110577	1	screw m 8 x 25
7	04161492	1	division
9	01107548	27	washer 8.4
10	01118783	1	oil seal
11	01118989	1	plug
12	03362581	1	gasket



ENGINE FRONT COVER

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[M 1202 SUPER]


1	01236291	1	plug
2	01216293	1	oil seal
9	04158421	1	cover
10	01107101	5	washer 8.4
12	01111179	3	screw m 8 x 70, d931
12	01127046	1	screw m 8 x 60
13	01174193	2	screw m 8 x 55
14	01216108	2	washer
15	01112824	2	nut m 8, d934
16	04152348	1	ring
17	01107556	16	washer
18	01127679	4	spring washer
19	01102281	4	screw m14x100 d912
20	01115460	1	pin
21	01102799	2	washer 8, d128
22	01112295	1	screw m 8 x 10
23	01122399	1	screw
24	01165788	1	plug m 18 x 1,5
25	01166111	1	oil seal
26	04152404	1	cover
27	01102800	1	washer 10.2
28	01111336	1	screw m 10 x 75
32	01118673	1	oil seal
33	01110422	1	screw
34	01007910	1	compound 1 kg
35	02237638	1	spring
36	02135019	1	tube
37	01118750	1	oil seal
38	04230057	1	screw

☞ 4A.00.20000

☞ 4A.00.20000

☞ 4A.00.20000

☞ 4A.00.20000



M 1202 SUPER

Section: ENGINE


Ref: 4A.00.20000

ENGINE COVER WITH IDLER PULLEY

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[M 1202 SUPER]



1	04152510	1	tensioner
2	04152520	1	pulley
3	02134806	1	tensioner
4	02133837	1	pulley
5	02133835	1	bush
6	02136433	1	washer
7	02136432	1	ring
8	01172655	1	ring rk 17x40x12
9	01124457	1	screw m 8 x 45
10	04152509	1	shim
10	04152517	1	shim
11	01107101	1	washer 8.4
12	01122477	1	nut m 8 p.1.25
13	02237847	1	cover
14	01136951	3	screw
15	02136434	1	gasket
16	04152519	1	lever
17	04191001	1	push-button
18	01174192	1	screw
19	01174191	1	screw m 8 x 25
20	01166111	1	oil seal
21	01216108	3	washer
22	01112824	2	nut m 8, d934
23	04153128	1	cover
24	04153130	1	cover
25	02238022	2	bushing
26	02238021	1	spring
27	02238081	1	shaft
28	02238083	1	washer
30	01157364	1	grub screw
31	02134884	1	washer
32	02238196	3	washer
34	02238084	1	bushing
35	02238056	1	ring
36	01174194	1	screw

Section: ENGINE


ENGINE STOP-SWITCH MOUNTING

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[M 1202 SUPER]

2	04191001	1	push-button
3	02245062	1	console
4	01101294	1	nut
5	02248490	1	tube
6	04154610	1	console
7	01171763	1	screw m 8 p.1.25 x 20
8	01172979	1	band
9	03382693	1	washer
10	02245054	1	socket



Section: ENGINE

ENGINE OIL PUMP

Fig.	P/n	QTY	Name
------	-----	-----	------

Notes:

[M 1202 SUPER]

1	04151832	1	primer
2	01210230	1	screw
3	01210231	1	ring
4	01112297	2	screw m8x12 d933
5	01102799	2	washer 8, d128
6	01103316	2	screw m 6 p.1.0 x 16
7	01117861	2	washer
8	01112813	2	nut m 6
9	02134631	2	fascia
10	04230653	1	oil pump
11	01172303	2	washer
12	02238751	1	division
13	01119611	1	ring
14	01110606	2	screw
15	01174605	2	oil seal
16	02239984	1	tube
17	04157058	1	bracket

