


Page Title	Page Number
9N130 CYLINDER BLOCK GROUP	2
9N3120 CYLINDER BLOCK GROUP	3
9L6065 CYLINDER BLOCK COVER GROUP	4
CRANKSHAFT (9N310N/S)	5
CRANKSHAFT (9N315N/S)	6
9N2017 CRANKSHAFT GROUP	7
9N2133 CRANKSHAFT GROUP	8
9N542 CRANKSHAFT SEAL GROUP	9
9N787 PULLEY AND DAMPER GROUP	10
9N150 CONNECTING ROD AND PISTON GROUP - 8 REQUIRED	11
9N1105 CYLINDER HEAD GROUP (SERIAL NUMBER 90N6235 - UP)	12
VALVE MECHANISM (9N487 N/S)	13
LIFTING (9N191 N/S) - R.H. SIDE	14
FRONT HOUSING (9N1080 N/S)	15
FRONT HOUSING COVER (9N560 N/S)	16
FLYWHEEL GROUP (4N8852 N/S)	17
FLYWHEEL HOUSING (4N5870 N/S)	18
FLYWHEEL HOUSING COVER (4N5866 N/S)	19
OIL PAN (4N8853 N/S) - CENTER SUMP	20
OIL LEVEL GAUGE (4N8855 N/S)	21
OIL PUMP (9N541 N/S)	22
OIL LINES (4N8854 N/S) - CENTER SUMP	23
OIL COOLER (9N521 N/S)	24
4N8856 WATER LINES GROUP (SERIAL NUMBER 90N12707 - UP)	25
9N140 WATER PUMP GROUP	26
9N140 WATER PUMP GROUP	59
EXHAUST MANIFOLD (9N535 N/S)	27
9N555 INLET MANIFOLD GROUP	28
9N555 INLET MANIFOLD GROUP	61
3N2915 AIR CLEANER ADAPTER GROUP	29
3N2915 AIR CLEANER ADAPTER GROUP	62
POSITIVE CRANKCASE VENTILATION VALVE (9N735 N/S)	30
9N740 GOVERNOR AND FUEL PUMP DRIVE GROUP	31
6N3563 GOVERNOR AND FUEL INJECTION PUMP GROUP	32
GOVERNOR CONTROL (9L6743 N/S)	33
9N119 FUEL INJECTION LINES GROUP (SERIAL NO. 90N6550-UP)	34
9N435 FUEL FILTER LINES GROUP	35
4N4314 FUEL PRIMING PUMP GROUP	36
FUEL PRIMING PUM (4N5868 N/S)	37
FUEL SYSTEM FASTENERS (9L6925 N/S)	38
NAME PLATES AND TRANSFERS (4N8943 N/S)	39
9L6553 CYLINDER BLOCK GROUP	40
9L6584 CYLINDER BLOCK COVER GROUP	41
4N7120 CRANKSHAFT GROUP (ONLY SEPARATE PARTS SERVICED)	42
4N5465 CRANKSHAFT GROUP (ONLY SEPARATE PARTS SERVICED)	43
9L6980 CONNECTING ROD AND PISTON GROUP - 8 REQUIRED	44
9N732 CYLINDER HEAD GROUP (ONLY SEPARATE PARTS SERVICED)	45
9N734 VALVE MECHANISM GROUP (ONLY SEPARATE PARTS SERVICED)	46
4N5871 LIFTING GROUP (ONLY SEPARATE PARTS SERVICED)	47
9N361 FRONT HOUSING GROUP (ONLY SEPARATE PARTS SERVICED)	48

4N5487 SUPPORT GROUP (ONLY SEPARATE PARTS SERVICED)	49
4N8852 FLYWHEEL GROUP (AN ATTACHEMENT)	50
4N5870 FLYWHEEL HOUSING GROUP (ONLY SEPARATE PARTS SERVICED)	51
4N5866 FLYWHEEL HOUSING COVER GROUP	52
4N8853 OIL PAN GROUP - CENTER SUMP	53
4N8855 OIL LEVEL GAUGE GROUP (ONLY SEPARATE PARTS SERVICED)	54
9N541 OIL PUMP GROUP (ONLY SEPARATE PARTS SERVICED)	55
4N8854 OIL LINES GROUP (ONLY SEPARATE PARTS SERVICED)	56
9N521 OIL COOLER GROUP (ONLY SEPARATE PARTS SERVICED)	57
4N8856 WATER LINES GROUP (ONLY SEPARATE PARTS SERVICED)	58
9N535 EXHAUST MANIFOLD GROUP (ONLY SEPARATE PARTS SERVICED)	60
9N735 POSITIVE CRANKSHAFT VENTILATION VALVE GROUP	63
9N731 GOVERNOR AND FUEL PUMP DRIVE GROUP	64
4N9231 GOVERNOR AND FUEL INJECTION PUMP GROUP	65
9L6743 GOVERNOR CONTROL GROUP (ONLY SEPARATE PARTS SERVICED)	66
4N5873 FUEL INJECTION LINES GROUP - PART 1	67
4N5872 FUEL FILTER LINES GROUP	68
4N5868 FUEL FILTER GROUP (ONLY SEPARATE PARTS SERVICED)	69
4N3287 FUEL PRIMING PUMP GROUP	70
9N543 AUXILIARY DRIVE PULLEY GROUP	71
AIR INTAKE AND ETHER START	72
MUFFLER AND EXHAUST	75
RADIATOR AND FAN (LATE PRODUCTION)	76
RADIATOR AND FAN (EARLY PRODUCTION)	79
FUEL TANK AND LINES	80
THROTTLE CONTROL LINKAGE	83
ELECTRICAL WIRING	84
ELECTRICAL WIRING	87
BATTERY BOX, BATTERY AND CABLES	88
ENGINE MOUNTS, ALTERNATOR,	91
STARTER AND SOLENOID	92
STARTER AND SOLENOID	95
ALTERNATOR (USED MACHINE SERIAL NUMBER 9C006492 AND UP)	96
ALTERNATOR	99
ALTERNATOR	99A
LIGHTING EQUIPMENT	100
WARNING LAMP	103
INSTRUMENT PANEL AND INSTRUMENTS	104
FRONT FRAME, REAR FRAME AND LADDER	107
DRAWBAR AND REAR AXLE TRUNNION	108
CLUTCH AND BRAKE CONTROLS	111
DRIVE SHAFT	115
CLUTCH	116
TRANSMISSION AND MOUNTS	119
TRANSMISSION	120
TRANSMISSION	123
TRANSMISSION	124
GEAR SHIFT	127
TRANSFER CASE, SHIFT LINKAGE	128
TRANSFER UNIT	131
UNIVERSAL DRIVES AND BRAKES	132
BRAKE	135

CENTER HOUSING (FRONT)	136
CENTER HOUSING (REAR)	139
DIFFERENTIAL (FRONT)	140
DIFFERENTIAL (REAR)	143
FRONT AND REAR AXLE (MF1505 AND 1805 TRACTOR)	144
FRONT AND REAR AXLE (MF1505 TRACTOR)	147
P.T.O. DRIVE	148
P.T.O. DRIVE SHAFT	151
P.T.O. GEAR BOX	152
P.T.O. DRIVE HYDRAULICS	155
P.T.O. DRIVE HYDRAULICS	159
STEERING AND OIL COOLER	163
AUXILIARY HYDRAULICS	167
AUXILIARY HYDRAULICS	171
AUXILIARY HYDRAULICS	172
HYDRAULIC VALVE - 2 SPOOL	175
HYDRAULIC VALVE - 2 SPOOL	176
HYDRAULIC VALVE - 2 SPOOL	179
HYDRAULIC VALVE - 2 SPOOL	180
HYDRAULIC VALVE - 3 SPOOL	183
HYDRAULIC VALVE - 3 SPOOL	184
HYDRAULIC VALVE - 3 SPOOL	187
HYDRAULIC VALVE - 3 SPOOL	188
HYDRAULIC VALVE - 3 SPOOL	195
HYDRAULIC VALVE (3 - SPOOL)	191
HYDRAULIC VALVE (3 - SPOOL)	192
FLOW DIVIDER BRAKE VALVES	196
HYDRAULIC OIL FILTER	199
HYDRAULIC PUMP	200
STEERING PUMP	203
STEERING CYLINDER	204
HOOD AND GRILLE	207
3 POINT HITCH	208
LIFT LINKS	211
LIFT LINK HYDRAULICS	212
SEAT AND SUSPENSION	215
SEAT (DELUXE VINYL)	219
SEAT SUSPENSION	220
SEAT (STANDARD)	223
SINGLE WHEELS	224
DUAL WHEELS	227
DUAL WHEELS	228
LABELS AND EMBLEMS	231
LABELS AND EMBLEMS (FRENCH)	231A
PAINT, SEALANT KIT, TRANSMISSION OIL	232
CAB	235
CAB, GLASS AND DOOR	236
CAB AIR CONDITIONING	240
COMPRESSOR	243
CAB PRESSURIZER	244
HEATER	247




9N130 CYLINDER BLOCK GROUP

9N130 CYLINDER BLOCK GROUP

Item	Part Number	Qty	Description
			(CATERPILLAR 3208 INDUSTRIAL ENGINE)

1	9L8412	1	Plug (.75 In. (19.05 MM Thread)
	2B858	1	Plug (.50 In. (12.70 MM Thread)
2	9L8002	8	Dowel
3	9L8072	5	Bearing
4	9L8992	5	Cap
5	9L7831	10	Bolt
	9L9009	10	Washer
6	3H5552	6	Plug

9N3120 CYLINDER BLOCK GROUP



9N3120 CYLINDER BLOCK GROUP

Item	Part Number	Qty	Description
(BASIC ENGINE)			

1	9L8412	1	Plug (.75 In. (19.05 MM Thread)
	2B858	1	Plug (.50 In. (12.70 MM Thread)
2	9L8002	8	Dowel
3	9L8072	5	Bearing
4	9L8992	5	Cap
5	9L7831	10	Bolt
	9L9009	10	Washer
6	3H5552	6	Plug